

**Equipment information**

**Equipment:** 00010457172  
**Type:** F 4L2011  
**Output:** 0000036,3 kW  
**Speed:** 1800 1/min  
**Build date:** 20.08.2007  
**KLU-Number:** 2500 6833/70118145  
**ETL scope:** EU406463  
**MVS:** 241

**VKU date:** 23.08.2007  
**VKU' date:** 26.10.2007  
**Commissioning date:**  
**Begin of guarantee period:** 26.04.2008  
**Man. begin of guar. period:** no  
**End of guarantee period:**  
**ID maintenance contract:**  
**ID insurance contract:**  
**Guarantee package:** 1

## Assembly group directory

**Equipment:** 00010457172  
**Output:** 0000036,3 kW  
**ETL scope:** EU406463

**Engine type:** F 4L2011  
**Speed:** 1800 1/min

CG	ETL-No.	Designation (en)	Designation (en)
<b>1</b>		<b>Crankcase</b>	
1	0506 9013	Screw plug	Screw plug
1	0507 7818	Dipstick	Dipstick
1	0507 9159	Engine block	Engine block
1	0507 9188	Rear end cover	Rear end cover
<b>2</b>		<b>Oil pan</b>	
2	0506 9057	Oil pan	Oil pan
<b>5</b>		<b>Crankshaft</b>	
5	0505 1754	Power take-off	Power take-off
5	0506 8138	Crankshaft	Crankshaft
5	0507 4151	Flywheel	Flywheel
5	0507 4230	Accessories	Accessories
<b>6</b>		<b>Connecting rod</b>	
6	0507 7881	Connecting rod	Connecting rod
<b>7</b>		<b>Piston</b>	
7	0507 9273	Piston	Piston
<b>8</b>		<b>Cylinder head</b>	
8	0506 7612	Filler cap	Filler cap
8	0506 9027	Valve mechan.cover	Valve mechan.cover
8	0507 4224	Fastenings	Fastenings
8	0507 4232	Cylinder head	Cylinder head
<b>10</b>		<b>Camshaft</b>	
10	0507 9021	Fastenings	Fastenings
10	0507 9109	Camshaft	Camshaft
10	0507 9197	Protection hood	Protection hood
10	0511 3695	Camshaft drive	Camshaft drive
<b>11</b>		<b>Timing gears</b>	
11	0505 1930	Rocker arm bracket	Rocker arm bracket
11	0506 7617	Valve drive	Valve drive
<b>14</b>		<b>Lube oil pump</b>	
14	0507 9248	Oil pump	Oil pump
<b>15</b>		<b>Lube oil/-cooler</b>	
15	0506 4400	Lubric. oil filter	Lubric. oil filter
15	0506 7780	Oil cooler	Oil cooler
15	0507 7896	Bracket	Bracket
15	0511 3697	Pilot line	Pilot line
<b>16</b>		<b>Oil pipes</b>	
16	0506 7624	Press.relief valve	Press.relief valve
16	0506 7625	Oil suction line	Oil suction line
<b>17</b>		<b>Injection pump</b>	
17	0506 7639	Screw plug	Screw plug
17	0511 3639	Fuel inject. pump	Fuel inject. pump
17	0511 4860	Fastenings	Fastenings
<b>19</b>		<b>Injector</b>	
19	0507 9013	Fuel injector	Fuel injector
<b>20</b>		<b>Fuel filter</b>	
20	0506 7542	Filter cartridge	Filter cartridge
20	0506 8026	Bracket	Bracket

<b>Equipment:</b>	00010457172	<b>Engine type:</b>	F 4L2011
<b>Output:</b>	0000036,3 kW	<b>Speed:</b>	1800 1/min
<b>ETL scope:</b>	EU406463		

CG	ETL-No.	Designation (en)	Designation (en)
20	0511 3678	Fuel supply pump	Fuel supply pump
<b>21</b>		<b>Fuel pipes/fuel tank</b>	
21	0507 9002	Fuel line	Fuel line
21	0507 9015	High pressure pipe	High pressure pipe
21	0507 9172	Fuel line	Fuel line
21	0507 9296	Fuel line	Fuel line
21	0507 9299	Fuel line	Fuel line
<b>22</b>		<b>Suction pipe/air cleaner</b>	
22	0505 1624	Flange	Flange
22	0505 1625	Air filter fitment	Air filter fitment
22	0506 3419	Blanking parts	Blanking parts
22	0507 4094	Suction pipe	Suction pipe
<b>27</b>		<b>Speed control</b>	
27	0506 3347	Blanking parts	Blanking parts
27	0506 7616	Control rod	Control rod
27	0507 7923	Limit stop	Limit stop
27	0507 9260	Front cover/govern	Front cover/govern
<b>33</b>		<b>Air compressor</b>	
33	0507 4236	Blanking parts	Blanking parts
<b>39</b>		<b>Cooling air blower</b>	
39	0505 1119	Tensioning pulley	Tensioning pulley
39	0506 3354	Narrow v-belt	Narrow v-belt
39	0506 7679	Sealing section	Sealing section
39	0506 7683	Blower jacket	Blower jacket
39	0507 9237	Cooling fan	Cooling fan
<b>40</b>		<b>Cooling air ducting</b>	
40	0506 7794	Air guide hood	Air guide hood
40	0506 8013	Sectional rubber	Sectional rubber
40	0506 8215	Air guidance	Air guidance
40	0507 4088	Fastenings	Fastenings
40	0507 9116	Air duct rear wall	Air duct rear wall
<b>41</b>		<b>Exhaust manifold</b>	
41	0506 3493	Exhaust silencer	Exhaust silencer
<b>44</b>		<b>Alternator/starter motor</b>	
44	0507 9006	Generator	Generator
44	0507 9244	Starter	Starter
<b>48</b>		<b>Electrical accessories</b>	
48	0506 7715	Electric line	Electric line
48	0506 7765	Transmitter mount.	Transmitter mount.
48	0506 8111	Fastenings	Fastenings
48	0507 9274	Fastenings	Fastenings
48	0507 9276	Fastenings	Fastenings
48	0507 9277	Fastenings	Fastenings
48	0507 9279	Fastenings	Fastenings
<b>51</b>		<b>Measuring instruments</b>	
51	0506 8119	Pressure sensor	Pressure sensor
51	0511 3694	Temper.transmitter	Temper.transmitter
<b>52</b>		<b>Clutch</b>	
52	0505 1756	Cover plate	Cover plate
52	0506 3423	Connection housing	Connection housing

**Equipment:** 00010457172  
**Output:** 0000036,3 kW  
**ETL scope:** EU406463

**Engine type:** F 4L2011  
**Speed:** 1800 1/min

CG	ETL-No.	Designation (en)	Designation (en)
<b>56</b>		<b>Engine shutdown</b>	
56	0507 9085	Shutdown device	Shutdown device
56	0507 9139	Fastenings	Fastenings
56	0507 9140	Blanking parts	Blanking parts
<b>90</b>		<b>Set of parts</b>	
90	0506 8247	Supplem.gasket set	Supplem.gasket set
90	0507 7823	Gasket set	Gasket set
<b>98</b>		<b>Optional extras</b>	
98	0118 0396	Blind rivet	Blind rivet
98	0211 2403	Locking screw	Locking screw
98	0417 0886	Compression spring	Compression spring