

MTU_ValueService **Technical Documentation**

Diesel Engine

**12 V 2000 G25, G25-TB, G45, G45-TB
G65, G65TB, G85**

**16 V 2000 G25, G25-TB, G45, G45-TB,
G65, G65-TB**

18 V 2000 G65, G65-TB, G85

Instructions for Exchange
of Sub-assemblies

MS22019/00E



Printed in Germany

© 2007 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services. This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

1	General Information	07
1.1	Important Notes	07
1.1.1	Prerequisites for maintenance work and general assembly instructions	07
1.2	General Conditions	09
1.2.1	General Instructions	09
1.2.2	Personnel and organizational requirements	10
1.2.3	Safety precautions when working on the engine	11
1.2.4	Auxiliary materials, fire prevention and environmental protection	14
1.2.5	Standards for warning notices in the publication	16
1.2.6	General information regarding the Tolerances and Wear Limits List	17
1.2.7	Engine side and cylinder designations	18
1.2.8	Tightening specifications for screws, nuts and bolts	19
1.2.9	Settings	31
1.2.10	Conversion tables	34
1.2.11	Repairing threaded bores with threaded inserts (Heli-Coil)	40
1.2.12	Abbreviations	42
2	Task Descriptions	45
2.1	Engine Casing and Add-on Components	45
2.1.1	Cylinder liner – Overview	45
2.1.2	Cylinder liner – Preparatory steps	46
2.1.3	Cylinder liner – Removal	47
2.1.4	Cylinder liner – Cleaning	49
2.1.5	Cylinder liner – Check	50
2.1.6	Cylinder liners – Tolerances	51
2.1.7	Cylinder liner – Installation	53
2.1.8	Cylinder liner – Final steps	56
2.1.9	Oil pan – Overview	57
2.1.10	Oil pan – Preparatory steps	60
2.1.11	Oil pan – Removal	61
2.1.12	Oil pan – Check	62
2.1.13	Oil pan – Installation	63
2.1.14	Oil pan – Final steps	64
2.1.15	Engine lifting equipment – Overview	65
2.1.16	Crankcase breather – Overview	66
2.2	Running Gear	69
2.2.1	Vibration damper on PTO, free end – Overview	69
2.2.2	Vibration damper on PTO, free end – Preparatory steps	74
2.2.3	Vibration damper on PTO, free end – Removal	75
2.2.4	Vibration damper on PTO, free end – Installation	77
2.2.5	Vibration damper on PTO, free end – Final steps	80
2.2.6	Drive flange on PTO, free end – Overview	81
2.2.7	Drive flange on PTO, free end – Preparatory steps	84
2.2.8	Drive flange on PTO, free end – Removal	85
2.2.9	Drive flange on PTO, free end – Tolerances	87
2.2.10	Drive flange on PTO, free end – Installation	90
2.2.11	Drive flange on PTO, free end – Final steps	93

2.2.12	Piston and conrod – Overview	94
2.2.13	Piston and conrod – Preparatory steps	96
2.2.14	Piston and conrod – Removal	97
2.2.15	Piston and conrod – Disassembly	99
2.2.16	Piston – Cleaning	101
2.2.17	Piston – Check	102
2.2.18	Piston – Tolerances	105
2.2.19	Conrod – Check	109
2.2.20	Conrod – Tolerances	111
2.2.21	Conrod – Assembly	115
2.2.22	Piston and conrod – Assembly	117
2.2.23	Piston and conrod – Installation	121
2.2.24	Piston and conrod – Final steps	125
2.3	Cylinder Head	126
2.3.1	Cylinder head with attachments – Overview	126
2.3.2	Cylinder head – Overview	127
2.3.3	Cylinder head – Preparatory steps	130
2.3.4	Cylinder head – Removal	131
2.3.5	Cylinder head – Cleaning	132
2.3.6	Cylinder head – Installation	133
2.3.7	Cylinder head – Final steps	135
2.4	Valve Gear	136
2.4.1	Valve drive – Overview	136
2.4.2	Valve drive – Preparatory steps	138
2.4.3	Valve drive – Removal	139
2.4.4	Valve drive – Cleaning	140
2.4.5	Valve drive – Check	141
2.4.6	Valve drive – Installation	142
2.4.7	Valve drive – Final steps	144
2.5	High-Pressure Fuel System	145
2.5.1	Injection pump – Overview	145
2.5.2	Injection pump – Preparatory steps	146
2.5.3	Injection pump – Removal and installation	147
2.5.4	Injection pump – Final steps	148
2.6	Low-Pressure Fuel System	149
2.6.1	Fuel delivery pump – Overview	149
2.6.2	Fuel delivery pump – Preparatory steps	150
2.6.3	Fuel delivery pump – Removal	151
2.6.4	Fuel delivery pump – Cleaning	152
2.6.5	Fuel delivery pump – Check	153
2.6.6	Fuel delivery pump – Installation	154
2.6.7	Fuel delivery pump – Final steps	155
2.6.8	Fuel pipework from fuel delivery pump to fuel filter – Overview	156
2.6.9	Leak-off fuel system – Overview	157
2.7	Exhaust Turbocharger	158
2.7.1	Exhaust turbocharger – Overview	158
2.7.2	Exhaust turbocharger – Preparatory steps	160
2.7.3	Exhaust turbocharger – Removal	161

2.7.4	Exhaust turbocharger – Cleaning	162
2.7.5	Exhaust turbocharger – Check	163
2.7.6	Exhaust turbocharger – Installation	164
2.7.7	Exhaust turbocharger – Final steps	165
2.8	Intercooler	166
2.8.1	Charge-air cooling – Overview	166
2.8.2	Intercooler – Preparatory steps	167
2.8.3	Intercooler – Removal	168
2.8.4	Intercooler – Installation	169
2.8.5	Intercooler – Final steps	170
2.9	Air Intake/Air Supply	171
2.9.1	Intake elbow – Overview	171
2.9.2	Intake elbow – Preparatory steps	172
2.9.3	Intake elbow – Removal	173
2.9.4	Intake elbow – Installation	174
2.9.5	Intake elbow – Final steps	175
2.9.6	Air pipework to cylinders – Overview	176
2.9.7	Air pipework to cylinders – Preparatory steps	178
2.9.8	Air supply pipework to cylinders – Removal	179
2.9.9	Air pipework to cylinders – Installation	180
2.9.10	Air pipework to the cylinders – Final steps	181
2.10	Exhaust Pipework	182
2.10.1	Exhaust pipework after cylinder – Overview	182
2.10.2	Exhaust pipework after cylinder head – Preparatory steps	183
2.10.3	Exhaust pipework after cylinder – Removal	184
2.10.4	Exhaust pipework after cylinder head – Installation	185
2.10.5	Exhaust pipework after cylinder head – Final steps	186
2.10.6	Exhaust pipework after exhaust turbocharger – Overview	187
2.10.7	Exhaust pipework after exhaust turbocharger – Removal	189
2.10.8	Exhaust pipework after exhaust turbocharger – Installation	190
2.11	Starting Equipment	191
2.11.1	Electric starter – Overview	191
2.11.2	Starter – Removal	193
2.11.3	Starter – Cleaning	194
2.11.4	Starter – Check	195
2.11.5	Starter – Installation	196
2.11.6	Starter – Overview	197
2.11.7	Starter – Preparatory steps	199
2.11.8	Starter – Removal	200
2.11.9	Starter – Cleaning	201
2.11.10	Starter – Check	202
2.11.11	Starter – Installation	203
2.11.12	Starter – Final steps	204
2.12	Lube-oil System, Lube-oil Circuit	205
2.12.1	Oil pump connections – Overview	205
2.12.2	Oil pump connections – Preparatory steps	206
2.12.3	Oil pump connections – Removal	207
2.12.4	Connections for oil pump – Cleaning	208

2.12.5	Connections for oil pump – Check	209
2.12.6	Oil pump connections – Installation	210
2.12.7	Oil pump connections – Final steps	211
2.12.8	Turbocharger oil supply – Overview	212
2.12.9	Exhaust turbocharger oil supply – Removal	213
2.12.10	Oil supply pipework for exhaust turbochargers – Cleaning	214
2.12.11	Oil supply pipework for exhaust turbochargers – Check	215
2.12.12	Oil supply pipework for exhaust turbochargers – Installation	216
2.12.13	Turbocharger oil return – Overview	217
2.12.14	Oil return line from exhaust turbocharger – Removal	218
2.12.15	Oil return line from exhaust turbochargers – Cleaning	219
2.12.16	Oil return line from exhaust turbochargers – Check	220
2.12.17	Oil return line from exhaust turbocharger – Installation	221
2.12.18	Oil return line from exhaust turbochargers – Final steps	222
2.13	Coolant System	223
2.13.1	Engine coolant pump – Overview	223
2.13.2	Engine coolant pump – Preparatory steps	224
2.13.3	Engine coolant pump – Removal	225
2.13.4	Engine coolant pump – Cleaning	226
2.13.5	Engine coolant pump – Check	227
2.13.6	Engine coolant pump – Installation	228
2.13.7	Engine coolant pump – Final steps	229
2.13.8	Coolant pipework from / to intercooler – Overview	230
2.13.9	Coolant pipework from / to intercooler – Preparatory steps	231
2.13.10	Coolant pipework from / to intercooler – Removal	232
2.13.11	Coolant pipework from / to intercooler – Installation	233
2.13.12	Remove coolant pipework from / to intercooler – Final steps	234
2.13.13	Coolant pipework with thermostat – Overview	235
2.13.14	Coolant pipework with thermostat – Preparatory steps	237
2.13.15	Coolant pipework with thermostat – Removal	238
2.13.16	Coolant pipework with thermostat – Cleaning sealing faces	240
2.13.17	Coolant pipework with thermostat – Check	241
2.13.18	Coolant pipework with thermostat – Installation	242
2.13.19	Coolant pipework with thermostat – Final steps	244
2.13.20	Coolant pipework with thermostat, charge-air coolant circuit – Overview	245
2.13.21	Coolant pipework with thermostat, charge-air coolant circuit – Preparatory steps	246
2.13.22	Coolant pipework with thermostat, charge-air coolant circuit – Removal	247
2.13.23	Coolant pipework with thermostat, charge-air coolant circuit – Cleaning	249
2.13.24	Coolant pipework with thermostat, charge-air coolant circuit – Check	250
2.13.25	Coolant pipework with thermostat, charge-air coolant circuit – Installation	252
2.13.26	Coolant pipework with thermostat, charge-air coolant circuit – Final steps	254
2.14	Power Supply, Engine Side	255
2.14.1	Battery charger – Overview	255
2.14.2	Battery-charging generator – Preparatory steps	258
2.14.3	Battery-charging generator – Removal	259
2.14.4	Battery-charging generator – Installation	260
2.14.5	Battery-charging generator – Final steps	261
2.15	Cooling Air System	262

2.15.1	Mechanical fan drive – Overview	262
2.15.2	Mechanical fan drive – Removal	271
2.15.3	Mechanical fan drive – Installation	272
2.16	Monitoring and Control Devices	273
2.16.1	Wiring and engine wiring harnesses – Overview	273
2.16.2	Engine wiring harnesses – Removal	277
2.16.3	Engine wiring harnesses – Installation	278
2.16.4	Engine wiring harnesses – Final steps	279
2.16.5	Sensors, actuators and injectors – Overview	280
2.16.6	Sensors, actuators and injectors – Preparatory steps	281
2.16.7	Sensors, actuators, and injectors – Removal	282
2.16.8	Sensors, actuators and injectors – Check	284
2.16.9	Sensors, actuators and injectors – Installation	285
2.16.10	Sensors, actuators and injectors – Final steps	287
3	Special Tools	289
3.1	Standard tools – Overview	289
3.2	Special tools – Overview	290
3.3	General workshop equipment – Overview	313
4	Appendix	319
4.1	Manufacturer's documentation	319
4.2	MTU contact/service partner	320
4.3	Index	326


1.2.8 Tightening specifications for screws, nuts and bolts

Crank drive

Designation	Torque specification	Lubricant
Screw for counterweight - Nominal length: 82.5 mm to 83.0 mm - Max. length: 84 mm		Engine oil
1 Pretightening torque	140 Nm +20 Nm	
2 Angle of further rotation	90° +10°	
Screw for flywheel on hub	270 Nm +27 Nm	
Screw for flywheel on ring gear	42 Nm +4 Nm	
Screw for viscosity vibration damper on drive flange	31 Nm +3 Nm	
Conrod screw - Nominal length: 73.2 mm to 73.5 mm - Max. elongation: 74.5 mm		
1 Pre-application torque Sequence: a Short arm b Long arm	100 Nm +15 Nm	
2 Angle of further rotation Sequence: a Short arm b Long arm	90° +10°	

Cylinder head

Designation	Torque specification	Lubricant
Protective sleeve for injector	45 Nm +5 Nm	Engine oil
Screw for cylinder head. - Nominal length: 209.5 mm to 210.0 mm - Max. length: 212 mm		
Tightening sequence of screws: 1 to 4		
Pretightening torque		
1st stage	10 Nm	
2nd stage	50 Nm	
3rd stage	100 Nm	
4th stage	200 Nm	
Angle of further rotation		
1st stage	90° +10°	
2nd stage	90° +10°	



2.2.14 Piston and conrod – Removal

Preconditions

- Preparatory steps have been completed.

Special tools

Designation / Use	Part No.	Qty.
Removal device	F6782138	1



Suspended load.

Danger to life!

- Use appropriate lifting devices and appliances.
- Never stand beneath a suspended load.



Heavy object.

Risk of crushing!

- Use appropriate lifting devices and appliances.



Contamination of components.

Damage to component!


- Observe manufacturer's instructions.
- Check components for special cleanliness.

Removing piston and conrod


1. Remove combustion residues in cylinder liner.
2. Remove carbon scraper ring (→ Page 47).
3. Install barring device (→ Operating Instructions).
4. Turn piston of relevant cylinder to BDC.

Note: Bearing cap and conrod form a unit and must not be interchanged.

5. Check marking (arrowed) of conrod bearing cap and conrod. If necessary, mark components.




6. Loosen piston screws from below (arrowed) using socket and ratchet.
7. Remove conrod screws (arrowed) and conrod cap (1).
8. Remove bearing shell from conrod cap (1).
9. Protect bearing shell and conrod cap from damage.
10. Turn piston of relevant cylinder to TDC.




11. Install removal device (1) in piston.

Note: Take care that the oil spray nozzle is not damaged.

12. Pull piston and conrod out of cylinder liner.
13. Remove bearing shell from conrod and protect from damage.
14. Carefully set piston and conrod down on soft surface.
15. Detach removal device from piston crown.
16. Close openings using suitable covers.



Piston clearance in cylinder liner



No.	Designation	Stage	Tol. size Basic size	Deviation		Clearance		Interference		Limit value
				Lower	Upper	Min.	Max.	Min.	Max.	
1	Piston clearance			−0.260	−0.220					
2	Liner dia.		130.000	−0.005	+0.005	0.503	0.537			
	Piston skirt dia.		129.480	−0.012	+0.012					
3	Liner dia.		130.000	−0.005	+0.005	0.237	0.263			
	Piston skirt dia.		129.750	−0.008	+0.008					
4	Liner dia.		130.000	−0.005	+0.005	0.148	0.172			
	Piston crown dia.		129.840	−0.007	+0.007					
Dimensions 2 to 4 measured in vertical position to the piston pin axis.										
5	Piston skirt has crowned oval shape									

2.2.19 Conrod – Check

Special tools

Designation / Use	Part No.	Qty.
Testing device	Y4341492	1
Test mandrel	Y4341915	1
Test mandrel	Y4341916	1
Bore gauge, 100-160 mm	Y20091481	1
Dial gauge	Y20011268	1
Depth gauge, 300 mm	Y20002777	1

Spare parts

Designation / Use	Part No.	Qty.
Conrod		
Conrod screw		
Conrod bushing		

Conrod – Check

Item	Findings	Task
Check conrod main bore for blue discoloration.	Blue discoloration	Replace conrod.
Check conrod bushing for scores, contamination, stress marks and heat discoloration marks.	Damaged	• Recondition • Replace conrod bushing.
Check threads of conrod and conrod screw for damage.	Damaged	• Replace conrod. • Replace conrod screw.
Check conrod screw length. Values (→ Page 111)	Value exceeded	Replace
Check conrod bearing cap mating face for conrod screws for traces of wear and scoring.	• Wear • Scores visible	Replace
Check basic bore for wear and scores.	• Wear • Scores visible	• Recondition • Replace
Inspect toothing for damage and check wear pattern with engineer's blue.	Damaged	Replace

Measuring conrod main bore without bearing shells

1. Assemble conrod (→ Page 115).
2. Adjust bore gauge and measure conrod main bore. Values (→ Page 111).
3. If values are exceeded, replace conrod.