


Electronically controlled diesel injection in conjunction with MAN Monitoring Diagnostic System (MMDS)



EDC MS 6.4 - D08 marine engines

*Description, testing, interfaces,
4-20 mA engine triggering system and electric gearbox triggering system*



These instructions are intended to help you to repair the electronic Diesel control system properly.

In writing these instructions, we have assumed that you have the necessary knowledge of control systems for working on and with the electronic diesel control.

Important instructions which concern technical safety and protection of persons are emphasised as shown below.

**Danger:**

This refers to working and operating procedures which must be complied with in order to rule out the risk to persons.

**Caution:**

This refers to working and operating procedures which must be complied with in order to prevent damage to or destruction of material.

**Note:**

Explanations useful for understanding the working or operating procedure to be performed.

Best regards
MAN Nutzfahrzeuge Aktiengesellschaft
Nuremberg Plant

We reserve the right to make technical modifications in the course of further development.

© 2004 MAN Nutzfahrzeuge Aktiengesellschaft

Reprinting, copying or translation, even in the form of excerpts, is forbidden without the written permission of MAN. MAN expressly reserves all rights in accordance with the law on copyright.

MTDB

Technical status: 01.2004

51.99598–8091

	Page
Preface	1
Safety information	4
Electronic diesel control	6
System description	7
Abbreviations	9
Component description	12
Pedal travel sensor or 4–20 mA throttle lever signal	12
Temperature sensors for charge air and coolant	14
Boost pressure sensor – Electronic pressure sensor	15
RPM sensor	16
Injector and needle movement sensor	17
EDC control box	18
Engine control EDC MS 6.4	22
Pin assignment for engine control unit EDC 6.4 stage 2	24
Functional description	26
Radial piston distributor injection pump VP 44 MS 6.4	26
Fuel System Diagram VP44	42
Notes on operation	43
Varying the idle speed – EDC control box	43
Self-diagnosis	44
Flash code	45
Check-list	48
Troubleshooting chart	51
Troubleshooting program	54
Test	55
Mechanical engine control with pedal travel sensor (pedal travel sensor, throttle lever signal)	55
Electric engine control with 4–20 mA throttle lever signal	56
Delivery volume solenoid valve, injection pump (plausibility of activation time)	58
Charge-air temperature sensor (LTF)	59
RPM sensor (DZG, Flywheel)	60
Boost pressure sensor (LDF)	61
Coolant temperature sensor (WTF)	62
Pump control unit self-test (pump map not present)	63
Shutdown via delivery volume 0 (run-on test)	64
Undervoltage	65
Engine overspeed	66
Start of injection control deviation	67
Needle movement sensor (NBF)	68
Plausibility of solenoid valve cutout (MAB)	70
EDC control box for idle speed adjustment	71
CAN1 interface (FM, MMDS) module	72
Shutdown via relay redundant shutdown MAR (run-on test)	73
Main relay (K1)	74
Relay (K2)	75
Time-lag relay (K3)	76
Shutdown via monitoring module (run-on test)	77
Atmospheric pressure sensor (in control unit)	78
Pump control unit solenoid valve	79
Timeout: CAN signal FM / MMDS at EDC	80
Run-on control	81
Self-test pump control unit: solenoid valve voltage measurement	82
Fuel temperature (pump control unit)	83
CAN 2 interface (PSG-CAN) – bus off	84
CAN 2 interface (PSG-CAN) module	85
Shutdown via delivery volume solenoid valve (run-on test)	86

	Page
CAN 1 interface (FM, MMDS) – bus off	87
Pump speed sensor (IWZ signal)	88
Residual volume	89
Self-test pump control unit: Solenoid valve output stage	90
Injection timing mechanism (pump control unit)	91
Timeout: CAN signal PSG 1	92
Shutdown via voltage monitoring (run-on test)	93
Timeout: CAN signal MSG 1	94
Supply voltage pump control unit	95
CAN signal pump control unit (interface)	96
Speed sensor signal recording, pump control unit	97
Self-test pump control unit: EEPROM checksum	98
Self-test pump control unit: EEPROM status	99
Self-test pump control unit: ADC status	100
Self-test pump control unit: RAM	101
Polarity reversal speed sensor on flywheel	102
Engine control unit monitoring module (μ controller)	103
Pump control unit initialisation	104
Fault sending a CAN message	105
Test of shutdown paths	106
Plug connections	107
Engine terminal box	110
Location of sensors for combustion air system	117
Location of sensors for cooling system	118
Location of the speed sensor	119
Location of the needle movement sensor	120
Location of fuses	121
EDC diagnostic tools	122
MAN-Cats Diagnostics System	123
MAN-Cats – Software Description	125
EDC testing with socket box	142
Connections: Boatyard start / stop, emergency stop, charge indication, charge-air preheating, alarms	146
Engine start / stop: Bridge / Flybridge / Engine room	147
Emergency stop	148
Charge indication, charge-air preheater, alarms	149
Connection for electric throttle lever control with 4–20 mA output signal	150
Possible throttle lever control for D08 marine engines made by Bosch Rexroth:	
Marex SB and Mini Marex-C	155
Brief description of the 4–20 mA throttle lever control system Marex SB	157
Brief description of the 4–20 mA throttle lever control system Mini-Marex-C	165
Circuit diagram for MMDS 24 V	171
Circuit diagram for EDC 24 V	173
Connection diagram	175
Circuit diagram for MMDS 12 V	177
Circuit diagram for EDC 12 V	179
Wiring of MMDS individual components MMDS	181
Index	185