

Throttle lever control Mini-Marex-C



**MAN marine Diesel engines
D 28 range and model D 0836 LE 401**

Assembly, function, operation




Contents

**User's Manual
Mini-Marex-C -System**

For systems with actuator


323 699 446 0



**User's Manual
Mini-Marex-System**

For systems with actuator


323 699 448 0



Mini-Marex-E

Actuator

323 699 452 0



User's Manual **Mini-Marex-C -System**

For systems with actuator

323 699 446 0



Imprint

The copyright of this user's manual remains the property of Rexroth Mecman GmbH.

Included are instructions and technical drawings, which may not be reproduced or copied either in part or whole, nor may they be used for evaluation or distributed for competition purposes.

The diagrams and drawings used in this manual are for guidelines only and are not to be used for the actual design.

This edition supersedes all previous ones.

No part of this edition may be reproduced without our prior permission.

Order No. 883 890 039 3 / 02.2000

Rexroth Mecman GmbH
Department: Marine Technique
Bartweg 13, 30453 Hannover
Telephone: (0511) 2136-251
Fax: (0511) 2136-165

CONTENTS

1. SYSTEM INFORMATION

1.1	Explanation of symbols	page	1-1
1.2	Safety advises	page	1-1
1.3	System set-up	page	1-2

2. INSTALLATION

2.1	Control head	page	2-1
2.1.1	Outline dimensions	page	2-2
2.2	Control panel	page	2-3
2.2.1	Outline dimensions	page	2-4
2.3	Actuator	page	2-5
2.3.1	Outline dimensions	page	2-6

3. ELECTRICAL CONNECTION

3.1	Grounding	page	3-1
3.2	Assignment of actuator connectors	page	3-1
3.3	Power supply	page	3-2
3.4	Power supply cable and engine start interlock	page	3-2
3.4.1	Connection to power supply	page	3-2
3.4.2	Connection to engine start interlock	page	3-3
3.5	Connection to control panel cable	page	3-4
3.6	Connection to intercommunication cable	page	3-5
3.7	Gear control cable	page	3-6
3.7.1	Standard design	page	3-7
3.7.2	Special design	page	3-9
3.8	Throttle control cable	page	3-10
3.8.1	Standard	page	3-10
3.8.2	Special	page	3-12
3.9	Trolling control cable	page	3-13
3.10	Internal fuses	page	3-16

4. ADJUSTMENTS AND FUNCTIONS

4.1	Interface board	page	4-1
4.1.1	Function switch IV (overview)	page	4-1
4.2	Main board	page	4-2
4.2.1	Function switch I...III (overview)	page	4-3
4.3	Basic adjustments	page	4-4
4.3.1	Function switch I (main board)	page	4-4
4.3.2	Function switch II (main board)	page	4-6
4.3.3	Function switch IV (interface board)	page	4-9

CONTENTS

4.4	Adjustment of throttle control	page	4-11
4.4.1	Standard throttle cable	page	4-11
4.4.1.1	Idle speed	page	4-12
4.4.1.2	Full speed	page	4-14
4.4.1.3	Second idle speed	page	4-16
4.4.2	Special throttle cable	page	4-18
4.4.2.1	Idle speed	page	4-19
4.4.2.2	Full speed	page	4-19
4.4.2.3	Second idle speed	page	4-19
4.5	Alignment of control heads and enable remote stations	page	4-21
4.6	Final adjustments	page	4-23

5. SPECIAL FEATURES

5.1	Special features	page	5-1
5.1.1	Enable speed synchronization	page	5-1
5.1.2	Features of speed synchroization	page	5-3
5.2.1	Trolling	page	5-4
5.2.2	Enable trolling	page	5-5
5.2.3	Trolling adjustments	page	5-7
5.2.3.1	Maximum speed	page	5-8
5.2.3.2	Minimum slip position	page	5-10
5.2.3.3	Maximum slip position	page	5-12

6. OPERATING INSTRUCTIONS

6.1	Control head	page	6-1
6.1.1	„Neutral“ position	page	6-1
6.1.2	„Ahead / Astern“ Position	page	6-1
6.1.3	„Full Speed“ Position	page	6-2
6.2	Operation field – Control head	page	6-2
6.2.1	Push button „Station Transfer“	page	6-2
6.2.1.1	Feature "Warming Up"	page	6-2
6.2.1.2	Feature "Mute acoustic alarm"	page	6-3
6.2.2	Indicator light „Alarm“ L7 and L8	page	6-4
6.2.3	Push button „Syn./Trol.“ T2	page	6-4
6.2.3.1	Speed synchronization	page	6-5
6.2.3.2	Trolling	page	6-6
6.2.4	Buzzer	page	6-7
6.2.5	Indicator light „Command“ L2 and L3	page	6-7

CONTENTS

6.3	Operation field – Control panel	page	6-8
6.3.1	Push button “Station Transfer“	page	6-8
6.3.1.1	Feature “Warming Up“	page	6-8
6.3.1.2	Feature “Mute acoustic alarm“	page	6-9
6.3.2	Push button “Alarm / Lamp test“	page	6-10
6.3.3	Push button “Dimmer“	page	6-10
6.3.4	Push button “Special features“	page	6-11
6.3.4.1	Speed synchronization	page	6-11
6.3.4.2	Trolling	page	6-12
6.3.5	Indicator lamp “Remote Control ON“	page	6-13
6.3.6	Buzzer	page	6-13
6.3.7	Lighting of control head	page	6-14
6.4.1	Turning ON control with control heads used	page	6-15
6.4.2	Station Transfer	page	6-16
6.4.2.1	Interlocked Station Transfer	page	6-16
6.4.2.2	Free Station Transfer	page	6-17
6.5.1	Turning ON control with control panels used	page	6-18
6.5.2	Station Transfer	page	6-19
6.5.2.1	Interlocked Station Transfer	page	6-19
6.5.2.2	Free Station Transfer	page	6-20

7. FAULT CODE

7.1	Fault code	page	7-1
-----	------------	------	-----

8. BLOCK DIAGRAMS

8.1	Single engine propulsion	page	8-1
8.2	Twin engine propulsion	page	8-2
8.3	Connection with standard control cables	page	8-3
8.4	Connection with special control cables	page	8-4