

## **Electronic Diesel Control EDC M(S) 5 - D28 V marine engines**



*Description, testing, interfaces,  
4-20 mA engine triggering system and electric gearbox triggering system,  
Link to MMS (BEW 1) engine monitoring system*





### Dear Customer

These instructions are intended to help you to repair the electronic diesel control system properly.

In writing these instructions, we have assumed that you have the necessary knowledge of control systems for working on and with the electronic diesel control.

Best regards  
MAN Nutzfahrzeuge Aktiengesellschaft  
Nuremberg Plant

Since our products are in continuous development, we reserve the right to make technical modifications.

© 2000 MAN Nutzfahrzeuge Aktiengesellschaft  
Reprint, duplication or translation, as a whole or in part without the written approval of MAN is prohibited. MAN reserves all rights accorded by the relevant laws on copyright.

Safety instructions	4
Electronic diesel control	7
System description	8
Component description	11
Control unit plug connector	11
Injection pump	13
Electromagnetic fuel-delivery regulator	13
Electrohydraulic shut-off device EHAB	14
Pedal value transmitter or 4–20 mA throttle lever signal	16
Temperature sensors for charge air, coolant and fuel	18
Turbo pressure sensor	19
RPM sensor	20
EDC operating element	21
Notes on operation	23
Changing idle speed – EDC operating element	23
Self-diagnosis	25
Flash code	26
List of checking procedures	28
Troubleshooting chart	32
Troubleshooting program	35
Test	36
Mechanical engine triggering with pedal value transmitter (PWG, throttle lever signal)	36
Electrical engine triggering with 4–20 mA throttle lever signal	38
Boost air temperature sensor	40
Speed sensor	41
Boost pressure sensor	42
Control rod position transducer	43
Coolant temperature sensor	44
Fuel-delivery regulator	45
Auxiliary rpm sensor	46
Fuel temperature sensor	47
Undervoltage	48
Request button (brake)	49
Control unit	50
Engine overspeed	51
Multistage switch for engine speed	52
EDC operating element for idle speed setting	53
Main relay (K1)	54
Relay (K2)	55
Time-lag relay (K3)	56
Atmospheric pressure sensor (in control unit)	57
Electrohydraulic shut-off device EHAB	58
Control unit EEPROM computer, 1 fault	59
Control unit EEPROM computer, 2 faults	60
Stop button on engine room panel	61
Control unit (processor afterrunning)	62
Control unit, after-running watchdog fault	63

---

Control rod travel transmitter – loose contact .....	64
Plug connections .....	65
Engine terminal box .....	67
Arrangement of sensors for boost air system .....	69
Arrangement of sensors for cooling system .....	71
Arrangement of sensors for speed pickup and fuel system .....	72
Arrangement of sensors for coolant level and oil pressure .....	73
Arrangement of fuses .....	74
EDC-diagnose-tools .....	75
MAN-Cats System .....	76
MAN-Cats – Software Description .....	78
Description of EDC-Check with pinadapter .....	92
Engine start / stop: bridge / flybridge .....	93
Engine room / engine room panel:engine start / stop .....	94
Emergency stop .....	95
Connection for electric throttle lever control with 4–20 mA output signal .....	96
Signal isolation when EDC speed signal is used .....	101
Triggering of engine and gearbox .....	103
Brief description of the 4–20 mA throttle lever control system .....	106
Terminal connection diagram .....	113
Index .....	121