

Commissioning instructions



Marex OS II CR-MPC
MAN marine Diesel engines
D 28 range and model D 08



Dear Customer

This manual is intended to help you:

- Familiarize yourself with the components of the MPC-System
- Recognize the interaction of the individual MPC components
- Install the system correctly in the ship
- Rectify faults and malfunctions

This manual must be read together with Publication 51.99598–8128 “Common Rail System” and 51.99598–8133 “MAN-Monitoring Diagnostic System (MMDS)”.

This Publication was devised under the assumption that its readers will have the necessary basic knowledge of handling and working with marine engines and their electrical systems.

Best regards
MAN Nutzfahrzeuge Aktiengesellschaft
Nuremberg Plant

Since our products are in continuous development, we reserve the right to make technical modifications.

© 2006 MAN Nutzfahrzeuge Aktiengesellschaft

Reprinting, duplication or translation, in whole or in part, is not permitted without the written permission of MAN. MAN reserves all rights accorded by the relevant laws on copyright.

Preface	1
Safety Instructions	4
Components	6
Control head type 240	7
CR-MPC control unit installed in junction box	8
CAN bus connection cables and terminating resistors	9
Cables	9
Terminating resistors	9
Visual check of CAN bus wiring	10
Example of a CAN bus wiring with 3 engines and 2 control stations	11
Check of M12 cables	11
Activation of terminating resistors by DIP switches S1 and S2	12
CAN bus connections at the MAN junction box	13
Bus termination at control head type 240	13
Modification of system parameters	14
Operating elements and display	14
Example for navigation in the menu	15
Indication of special characters in the display	16
Selection of the "system parameters" menu	17
Selection of the language	18
Registration and configuration of control heads	19
Delete old IDs	20
Start automatic ID setting	21
ID setting for a control head	21
Complete and store automatic ID setting	23
Check of the assigned IDs	23
Registration of starboard control heads	24
Test of command transfer	24
Configuration of control heads (ab V4.12M)	25
Commissioning of cross communication	26
Portside parameterization	26
Starboard parameterization	26
Test of cross communication	27
Engine test	28
Trolling gears	29
General description for adjustment of trolling gears	29
Activation of trolling function	30
Trolling outputs	30
4–20 mA / 0–10 V output	31
Proportional valve output	32
Digital trolling output	35
Adjustment of ZF-Padova trolling gears	36
Adjustment of Twin Disc MG 5114 A trolling gears	39
Adjustment of Twin Disc MGX ETROLL trolling gears	42

Synchronisation	44
Reversing maneuver ahead – astern	45
Determination of the max. speed for reversal	45
Parameters for calculation of the ship velocity	46
Adjustment of control heads / re-parameterization	48
Reset parameters to state of delivery	50
Error indication and diagnosis	52
Error states of the “marex OS II”-system	52
Indication of errors at the control stations with type 240 control heads	53
Indication of errors at the CR-MPC control unit	53
Indication of actual errors	54
Indication of old errors(from V4.12M)	55
Delete list of old errors(from V4.12M)	58
MPC error messages	59
error lever	60
Operating panel error (not for standard CR-MPC)	63
Operating module error (not for standard CR-MPC)	66
MPC error	67
I/O module error (not for standard CR-MPC)	71
Error of IO DIOC 711 module (not for standard CR-MPC)	75
Error of IO AIC 711 module (not for standard CR-MPC)	77
Error of IO AOC 711 module(not for standard CR-MPC)	80
Error of IO DDC 711 module (not for standard CR-MPC)	83
Actuator error (not for standard CR-MPC)	86
Internal error	90
Parameter error	93
Error of multiple-engine systems	98
Gear error	99
Error of ship velocity	101
Engine speed error	102
Trolling error	105
Error of engine load (not for standard CR-MPC)	106
Error of external station (not for standard CR-MPC)	107
External error (not for standard CR-MPC)	109
Hints regarding measurement technique and the test of devices	113
Current measurement	113
Voltage measurement	113
Resistance measurement	113
CAN bus test	114
Test of terminating resistor	114
Continuity test	115
Test of the control CR-MPC	116
Self-test	116
Commissioning display	118
Index	123