


MAN Monitoring and Diagnostic System (MMDS)



D 28 in-line and V marine engines with EDC
D 28 V marine engines with mechanical governor

Description, checking, interfaces



Dear Customer

This manual is intended to help you:

- Familiarize yourself with the components of the MAN Monitoring Diagnostic System (MMDS for short)
- Recognize the interaction of the individual MMDS components
- Install the system correctly in the ship
- Rectify faults and malfunctions

This manual must be read together with Publication 51.99598–8043 “Electronically Controlled Diesel Injection in Conjunction with MAN Monitoring Diagnostic System (MMDS)”.

This Publication was devised under the assumption that its readers will have the necessary basic knowledge of handling and working with marine engines and their electrical systems.

Best regards
MAN Nutzfahrzeuge Aktiengesellschaft
Nuremberg Plant

Since our products are in continuous development, we reserve the right to make technical modifications.

© 2002 MAN Nutzfahrzeuge Aktiengesellschaft
Reprint, duplication or translation, as a whole or in part without the written approval of MAN is prohibited.
MAN reserves all rights accorded by the relevant laws on copyright.



Contents

	Page
Safety Instructions	4
Layout of MAN Monitoring Diagnostic System (MMDS)	6
System Description	10
Location of Sensors for Combustion Air System	14
Location of Sensors for Cooling System	18
Location of Sensors for Lube Oil System	19
Location of RPM sensors	20
Testing Sensors	21
Sensors for pressure measurement	21
Sensors for temperature measurement	22
Sensors for coolant level	26
Testing three-phase generator	27
Testing Sensors, engines with mechanical control	28
Testing Sensors, engines with mechanical control	29
Testing Sensors, special equipment	30
Sensors for engine monitoring	30
Sensors for gearbox monitoring	30
MMDS Central Diagnostic Unit in Terminal Box	31
Connection Diagram of MMDS Central Diagnostic Unit	45
Analog Indicating Instruments and Testing	46
MMDS-LC Display Unit	54
Technical data	60
Notes on maintenance	60
MMDS-LC Display Unit Function and Operation	61
MDS-LC Display Unit Programming Ship Alarms	71
Technical data	79
Notes on maintenance	79
MMDS-L Display Unit	75
MMDS-L Display Unit Connection Diagram	80
MMDS-SD Serial Distribution Box	81

	Page
MMDS-DA Digital/Analog Converter	86
Engine Room Panel of MMDS Diagnostic System	90
Commissioning	93
Connecting Cables	99
Circuit diagram for EDC and MMDS	103
EDC diagram	105
Connection diagram	107
Wiring of MMDS individual components MMDS	109
Circuit diagram for marine engines with mechanical controllers and MMDS	111
Circuit diagram for marine engines with mechanical controllers and MMDS	113