

## DESMI PUMPS

### Operation and Maintenance Manual with Spare Parts List.

**The following DESMI PUMPS are included in SET:**

**DESMI self-priming centrifugal pumps MODULAR S** - Operation and Maintenance Manual with Spare Parts List.

Type of Pumps: S-32-25-110, S-50-32-135, S-70-50-175, S-70-50-220, S-70-50-275, S-80-70-175, S-80-70-220, S-80-70-275, S-100-80-175, S-100-80-220, S-100-80-275, S-125-80-220, S-125-80-275, S-125-100-220.

**DESMI self-priming centrifugal pumps TYPE SA** - Operation and Maintenance Manual with Spare Parts List.

Type of Pumps: SA-20-90, SA-25-122, SA-35-135, SA-50-180, SA-65-250, SA-80-160, SA-80-220, SA-100-235, SA-125-235, SA-150-260, SA-200-320.

**DESMI ROTAN internal gear pumps Types GP – HD - PD - CD - CC – ED series** - Operation and Maintenance Manual with Spare Parts List.

**DESMI "in-line" centrifugal pumps SL Spacer** - Operation and Maintenance Manual with Spare Parts List.

SL 70-215, SL 70-265, SL 80-215, SL 80-265, SL 80-330, SL 100-215, SL 100-265, SL 100-330, SL 125-215, SL-125-265, SL 125-330, SL 125-415, SL 150-265, SL 150-330, SL 150-415, SL 200-265, SL 200-330, SL 200-415, SL 250-330, SL 250-415

**DESMI portable centrifugal pump SA50-T (50-135/14) HATZ 1B20/30** - Operation and Maintenance Instruction with Spare Parts List.

**DESMI vertical "in-line" centrifugal pump NSL Monobloc** - Operation and Maintenance Manual with Spare Parts List.

NSL80-215, NSL80-265, NSL80-330, NSL100-215, NSL100-265, NSL100-330, NSL100-415, NSL125-215, NSL125-265, NSL125-330, NSL125-415, NSL150-215, NSL150-265, NSL150-330, NSL150-415, NSL200-265, NSL200-330, NSL200-415, NSL250-265, NSL250-330, NSL250-415, NSL300-415, NSL300-525