

## FOP VIKTOR KNYAZYEV

Ap.62, Ak. Glushka 6, Odessa. 65113 Ukraine.

Registartion no. 2 556 000 0000 139668 / Tax. no. 1869801971

Spare parts: http://brovertek.com | Tech Library: http://engine.od.ua | Mariners support: http://MarEngine.com

Big Library of the Sounded Books for Children in English http://babyenglish.gift

E-mail: broverter@gmail.com / babyenglish.best@gmail.com / Phone: 38 0674831710

## INVOICE-OFFER No SET # 21 MAN (MAN B&W) 4-stroke diesel engines Date: To: Company name Address (optional) Country line Description Amount USD MAN (MAN B&W) 4-stroke GENSET diesel engines MAN B&W. Holeby diesel generator L16/24. Instructions Manual -1 L16/24 **Operation, Description and Maintenance, Components (Spare parts** \$62 list) STS (MAN B&W Holeby) diesel generator L16/24. Instructions Manual -2 L16/24 **Operation, Description and Maintenance, Components (Spare parts** \$62 list) MAN B&W. Holeby diesel generator L16/24. Instructions Manual -3 L16/24 **Operation, Description and Maintenance, Components (Spare parts** free list). RUSSIAN LANGUAGE HSD diesel L21/31 (MAN license) Instruction Book Vol. I and Vol. II -L21/31 HSD \$92 4 **Operations, Maintenance and Spare parts. Vol III - Fitting and** Accessories with spare parts lists. HYUNDAI diesel L21/31 (MAN license) Instruction Book Vol. I and Vol. 5 L21/31 HYUNDAI II - Operations, Maintenance and Spare parts. Vol III - Fitting and \$92 Accessories with spare parts lists. MAN diesel L21/31 Instruction Book - Operations, Maintenance and L21/31 \$62 6 Spare parts (Full manual disc). MAN B&W. Holeby diesel generator L23/30. Instructions Manual -7 L23/30 **Operation, Description and Maintenance, Components (Spare parts** \$52 list) STX L23/30H (Holeby Licenser) - Working Manual with Drawings, Spare 8 L23/30 STX \$52 Parts & Finished Plan MAN B&W L23/30H (China Licensee) - Full Instruction Manual with 9 L23/30 free Parts. MAN B&W. Holeby diesel generator L27/38. Instructions Manual -10 L27/38 **Operation, Description and Maintenance, Components (Spare parts** \$62 list) HYUNDAI diesel L27/38 (MAN license) Instruction Book Vol. I -11 L27/38 HYUNDAI **Operations, Maintenance and Spare parts. Vol II - Accessories with** \$92 spare parts lists. MAN B&W. Holeby. L28/32. Instructions Manual - Operation, 12 \$52 L28/32 Description and Maintenance, Components (Spare parts list) MAN B&W. Holeby diesel generator V28/32 Instructions - Operation \$52 13 V28/32 Manual, Components Description and Maintenance, Spare parts. MAN B&W. Holeby. L32/40. Instructions - B 1 Introduction, Technical 14 L32/40 \$22

details, Operation / oper. media, Maintenance / Repair.

L5	L32/40	MAN B&W. Holeby. L32/40. Instructions - B 2 Work cards, arranged by subjects/key words. Work cards, arranged by subassembly groups of	\$42
	202/70	the engine	<i>•</i> · -
_		MAN B&W. Holeby. L32/40. Instructions - B 3 Spare Parts Catalog and	4
16	L32/40	Engine Tools	\$52
_		MAN B&W. Holeby. L32/40. Instructions - B 1 Operation, Maintenance	4.4.4
L7	L32/40	(repair), Spare parts	\$92
		STX ENGINE CO. LTD Diesel Generator 6L32/40 CD (Holeby Licenser) -	
18	L32/40	Operating, Working & Repair Manuals. Spare parts catalog with	<b>\$92</b>
		Drawings include spares dimensions and weight.	
10	122/40	HYUNDAI Diesel Generator L32/40 (Holeby Licenser) - Operating,	\$92
19	L32/40	Working & Repair Manuals. Spare parts catalog.	39Z
20	T23L-4E	Diesel Engine T23L-4E. Spare Parts Catalogue.	\$42
21	T23HU (Litostroj)	Diesel Engine T23HU (Litostroj Licensee). Spare Parts Catalogue.	free
		ENGLISH and RUSSIAN LANGUAGES.	nee
		MAN B&W 4 stroke Propulsion Diesel Engine	
22	L23/30A	MAN B&W. Alpha. L23/30A. Instruction Manual (without spare parts	\$48
		drawings)	ŶĨŨ
23	L27/38	MAN B&W. Alpha. L27/38. Instruction Manual (without spare parts	\$48
		drawings).	¥ lo
24	L28/32A	MAN B&W. Alpha. L28/32A. Instruction Manual (without spare parts	\$48
		drawings)	
25	<u>V28/32A</u>	MAN B&W. Alpha. V28/32A. Instruction Manual (without spare parts	<u>\$48</u>
_		drawings).	
26	L32/40	MAN Augsburg diesel engine L32/40. Operating Instructions.	\$22
27	L32/40	MAN Augsburg diesel engine L32/40. Working (repair) Instructions.	\$42
28	L32/40	MAN Augsburg diesel engine L32/40. Spare Parts Catalogue.	\$52
29	V32/40	MAN Augsburg diesel engine V32/40. Operating Instructions.	\$22
30	V32/40	MAN Augsburg diesel engine V32/40. Working Instructions.	\$42
31 _	V32/40	MAN Augsburg diesel engine V32/40. Spare Parts Catalogue.	\$52
32	L40/45	MAN Augsburg diesel engine L40/45 - Operating & Maintenance	<b>\$22</b>
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	-	Manual.	-
33	L40/54	MAN Augsburg diesel engine L40/54. Operation Instruction.	\$22
34	L40/54	MAN Augsburg diesel engine L40/54. Working Instruction.	\$42
35 _	L40/54	MAN Augsburg diesel engine L40/54. Spare Parts Catalogue.	\$52
36	L48/60	MAN Augsburg diesel engine L48/60. Operating Instructions	\$22
37	L48/60	MAN Augsburg diesel engine L48/60. Working Instructions.	\$42
38 _	L48/60	MAN Augsburg diesel engine L48/60. Spare Parts Catalogue.	\$52
39	L48/60B	MAN Augsburg diesel engine L48/60 B. Operating Instructions	\$22
10	L48/60B	MAN Augsburg diesel engine L48/60 B. Working Instructions.	\$42
11 	L48/60B	MAN Augsburg diesel engine L48/60 B. Spare Parts Catalogue.	\$52
12	L58/64	MAN Augsburg diesel engine L58/64. Operating Instructions.	\$22
	L58/64	MAN Augsburg diesel engine L58/64. Working Instructions.	\$42 652
13	-		
14	L58/64	MAN Augsburg diesel engine L58/64. Spare Parts Catalogue.	\$52 ¢22
14 <u>–</u> 15	L58/64 L58/64CD	MAN Augsburg diesel engine L58/64 CD. Operating Instructions.	\$22
14 <u>–</u> 15 16	L58/64 L58/64CD L58/64CD	MAN Augsburg diesel engine L58/64 CD. Operating Instructions. MAN Augsburg diesel engine L58/64 CD. Working Instructions.	\$22 \$42
14 <u>–</u> 15 16	L58/64 L58/64CD	MAN Augsburg diesel engine L58/64 CD. Operating Instructions. MAN Augsburg diesel engine L58/64 CD. Working Instructions. MAN Augsburg diesel engine L58/64 CD. Spare Parts Catalogue.	\$22 \$42 \$52
14 <u>–</u> 15 16	L58/64 L58/64CD L58/64CD	MAN Augsburg diesel engine L58/64 CD. Operating Instructions. MAN Augsburg diesel engine L58/64 CD. Working Instructions. MAN Augsburg diesel engine L58/64 CD. Spare Parts Catalogue. Total:	\$22 \$42 \$52 2192
14	L58/64 L58/64CD L58/64CD	MAN Augsburg diesel engine L58/64 CD. Operating Instructions. MAN Augsburg diesel engine L58/64 CD. Working Instructions. MAN Augsburg diesel engine L58/64 CD. Spare Parts Catalogue. Total: Bulk discount 75%:	\$22 \$42 \$52 2192 -1644
14 <u>–</u> 15 16	L58/64 L58/64CD L58/64CD	MAN Augsburg diesel engine L58/64 CD. Operating Instructions. MAN Augsburg diesel engine L58/64 CD. Working Instructions. MAN Augsburg diesel engine L58/64 CD. Spare Parts Catalogue. Total:	\$22 \$42 \$52 2192

Terms of payment: Prepayment with company order

PAYMENT WAYS

See details on: <u>http://engine.od.ua/payment</u> or in PDF file: <u>PDF-Way-of-payment-VAK.pdf</u>