



FOP VIKTOR KNYAZYEV

Ap.62, Ak. Glushka 6, Odessa. 65113 Ukraine.

Registration no. 2 556 000 0000 139668 - Tax. no. 1869801971

Spare parts: <http://brovertek.com> | Tech Library: <http://engine.od.ua> | Mariners support: <http://MarEngine.com>

Big Library of the Sounded Books for Children in English <http://babyenglish.gift>

E-mail: broverter@gmail.com - babyenglish.best@gmail.com - Phone: 38 0674831710

OFFER-INVOICE No 22 MAN Manuals

Date:

To: **Company name**

Address (optional)

Country

line	Description	Amount USD
MAN Marine and Industrial Diesel Repair and Operation Manuals		
	REPAIR MANUAL	Folder name
101	D 2866 LE401	101-D2866-LE401-LE402-LE403-LE405,D2876-LE301-LE403
	D 2866 LE402	
	D 2866 LE403	
	D 2866 LE405	
	D 2876 LE301	
	D 2876 LE403	
102	D2840 LXE	102-D2848-LXE-LE401-403-405,D2840-LXE-LE401-402-407,D2842-LYE-LZE-LE401-402-403-406-408-411-412-413-RM
	D2840 LE401	
	D2840 LE402	
	D2840 LE407	
	D2842 LYE	
	D2842 LZE	
	D2842 LE401	
	D2842 LE402	
	D2842 LE403	
	D2842 LE406	
	D2842 LE408	
	D2842 LE411	
	D2842 LE412	
	D2842 LE413	
	D2848 LXE	
	D2848 LE401	
	D2848 LE403	
	D2848 LE405	
103	D2840 LE403	103-D2848-LE403-405,D2840-LE403,D2842-LE404-410-414-415-416-417-RM
	D2842 LE404	
	D2842 LE410	
	D2842 LE414	
	D2842 LE415	
	D2842 LE416	
	D2842 LE417	
	D2848 LE403	
	D2848 LE405	

104	D2840 LE 2..	104-D2848 LE2..,D2840 LE2..,D2842 LE2..-RM	18
	D2842 LE 2..		
	D 2848 LE 2..		
105	D 2842 LE602	105-D2842-LE602-604-606-607-RM	18
	D 2842 LE604		
	D 2842 LE606		
	D 2842 LE607		
106	D2876 LE401	106-D2876-LE401-402-404-405-RM	18
	D2876 LE402		
	D2876 LE404		
	D2876 LE405		
107	D 2866 LE 2..	107-D2866-LE2..-RM	18
108	D2876 LE101	108-D2876-LE101-103-104-105-RM	18
	D2876 LE103		
	D2876 LE104		
	D2876 LE105		
109	D0836 LE401	109-D0836-LE401-402,D0836-LE301-RM	18
	D0836 LE402		
	D0836 LE301		
110	D2866 LUE602	110-D2866-LUE602-605-RM	18
	D2866 LUE605		
111	D2876 LUE601	111-D2876-LUE601-602-603-604-605-606-RM	18
	D2876 LUE602		
	D2876 LUE603		
	D2876 LUE604		
	D2876 LUE605		
	D2876 LUE606		
112	D2842 LE409	112-D2842-LE409-RM	18
113	D2848 LE423	113-D2848-LE423,D2840-LE423,D2842-LE423-433-443(CR)-RM	18
	D2840 LE423		
	D2842 LE423		
	D2842 LE433		
	D2842 LE443 (CR)		
114	D2876 LE201	114-D2876-LE201-202-203-RM	18
	D2876 LE202		
	D2876 LE203		
115	D2842 LE620	115-D2842-LE620-RM	18
116	D2840 LE301	116-D2840-LE301,D2842-LE301-RM	18
	D2842 LE301		
117	D2530 ME	117-D2530-ME-MTE,D2540-ME-MTE-MLE,D2840-ME-LE,D2842-ME-LE-RM	18
	D2530 MTE		
	D2540 ME		

	D2540 MTE		
	D2540 MLE		
	D2840 ME		
	D2840 LE		
	D2842 ME		
	D2842 LE		
118	D2565 ME	118-D2565-ME,D2566-ME-MTE-MLE,D2866-E-TE-LE-RM	18
	D2566 ME		
	D2566 MTE		
	D2566 MLE		
	D2866 E		
	D2866 TE		
	D2866 LE		
119	D2876 LE423	119-D2876-LE423-RM	18
120	D0836-LE-(Fendt)	120-D0836-LE-(Fendt)-RM	18
121	D2876 LF 12/13	121-D2876-LF-12-13--Common-Rail-RM (Engine Training)	18
122	D0834/36 Euro 3/4 CR E	122-D0834-36-CR-EDC7-RM (Engine Training)	18
123	D2876 LF 12/13	123-D2876-LF-12-13-Common-Rail-RM (Engine Training)	18
124	D 2066 LF.. CR EDC 7	124-D-2066-LF.-CR-EDC7-RM (Engine Training)	18
125	D2868 LE422	125-D2868-LE4..-(V8)-D2862-LE4..(V12)-RM	32
	D2868 LE423		
	D2868 LE425		
	D2868 LE426		
	D2868 LE433		
	D2868 LE436		
	D2862 LE423		
	D2862 LE425		
	D2862 LE426		
	D2862 LE432		
	D2862 LE433		
	D2862 LE435		
	D2862 LE436		
	D2862 LE442		
	D2862 LE443		
	D2862 LE446		
	D2862 LE453		
	D2862 LE456		
	D2862 LE463		
	D2862 LE466		
ENGINEERING, DATA, SETTING VALUES			
131	D2840 LE 2..	131-D2848-LE2..,D2840-LE2..,D2842-LE 2..-ED	18
	D2842 LE 2..		
	D 2848 LE 2..		
132	D2876 LE401	132-D2876-LE401-402-404-405-ED	18
	D2876 LE402		
	D2876 LE404		
	D2876 LE405		

133	D2866 LXE	133-D2866-LXE,D2866-LE401-2-3-5,D2876-LE301-403-ED	18
	D 2866 LE401		
	D 2866 LE402		
	D 2866 LE403		
	D 2866 LE405		
	D 2876 LE301		
	D 2876 LE403		
134	D2848 LXE	134-D2848-LXE-LE40, D2840 LXE / LE4., D2842 LYE / LZE / LE4.-ED	18
	D2848 LE401		
	D2848 LE403		
	D2848 LE405		
	D2840 LXE		
	D2840 LE401		
	D2840 LE402		
	D2840 LE407		
	D2842 LYE		
	D2842 LZE		
	D2842 LE401		
	D2842 LE402		
	D2842 LE403		
	D2842 LE406		
	D2842 LE408		
	D2842 LE411		
	D2842 LE412		
	D2842 LE413		
135	D0836 LE401	135-D0836-LE401-402-ED	18
	D0836 LE402		
136	D2866 LE201	136-D2866-LE201-202-203-ED	18
	D2866 LE202		
	D2866 LE203		
OPERATING INSTRUCTIONS			
201	D2866 E	201-D2866-E-TE-LE-LXE-OM	8
	D2866 TE		
	D2866 LE		
	D2866 LXE		
202	D2876 LE401	202-D2876-LE401-402-404-405-OM	8
	D2876 LE402		
	D2876 LE404		
	D2876 LE405		
203	D2848 LE401	203-D2848-LE401-403-405,D2840-LE401-402-407,D2842-LE401-402-403-406-408-411-412-413-OM	8
	D2848 LE403		
	D2848 LE405		
	D2840 LE401		
	D2840 LE402		
	D2840 LE407		
	D2842 LE401		
	D2842 LE402		
	D2842 LE403		

	D2842 LE406		
	D2842 LE408		
	D2842 LE411		
	D2842 LE412		
	D2842 LE413		
204	D2840 LE301	204-D2840-LE301,D2842-LE301-OM	8
	D2842 LE301		
205	D2840 LE403	205-D2840-LE403,D2842-LE404-407-410-414-415-416-417-OM	8
	D2842 LE404		
	D2842 LE407		
	D2842 LE410		
	D2842 LE414		
	D2842 LE415		
	D2842 LE416		
	D2842 LE417		
206	D2866 LE401	206-D2866-LE401-402-403-405,D2876-LE403-OM	8
	D2866 LE402		
	D2866 LE403		
	D2866 LE405		
	D2876 LE403		
207	D2848 LE201	207-D2848-40-42-LE201-202-203-211-212-213-OM	8
	D2848 LE202		
	D2848 LE203		
	D2848 LE211		
	D2848 LE212		
	D2848 LE213		
	D2840 LE201		
	D2840 LE202		
	D2840 LE203		
	D2840 LE211		
	D2840 LE212		
	D2840 LE213		
	D2842 LE201		
	D2842 LE202		
	D2842 LE203		
	D2842 LE211		
	D2842 LE212		
	D2842 LE213		
208	D2866 TUE	208-D2866-TUE-OSE-OM	8
	D2866 OSE		
209	D2842 ME601	209-D2842-ME601-OM	8
210	D0824 LE201	210-D0824-LE201-OM	8
211	D0826 LE	211-D0826-LE-LE201-OM	8
	D0826 LE201		
212	D0836 LE401	212-D0836-LE401-402-OM	8
	D0836 LE402		

213	D2866 LUE	213-D2866-LUE-LUE601-OM	8
	D2866 LUE601		
214	D2866 LE201	214-D2866-LE201-202-203-211-OM	8
	D2866 LE202		
	D2866 LE203		
	D2866 LE211		
215	D2876 LE101	215-D2876-LE101-102-103-105-OM	8
	D2876 LE102		
	D2876 LE103		
	D2876 LE105		
216	D2876 LUH01	216-D2876-LUH-01-OM	8
217	D2848 40LXE	217-D2848-40-42-LXE,D2842-LYE-LZE-OM	8
	D2848 42LXE		
	D2842 LYE		
	D2842 LZE		
218	D2842 LE409	218-D2842-LE409-OM	8
219	D0226 MTE	219-D0226-MTE-MLE-OM	8
	D0226 MLE		
220	D2848 LE	220-D2848-40-42-LE-OM	8
	D2840 LE		
	D2842 LE		
221	D0224 ME	221-D0224-ME,D0226-ME-OM	8
	D0226 ME		
222	D2866 LUE 602	222-D2866-LUE602-605-OM	8
	D2866 LUE 605		
223	D2876 LE201	223-D2876-LE201-202-203-OM	8
	D2876 LE202		
	D2876 LE203		
224	D2876 LE301	224-D2876-LE301-OM	8
225	D2848-LE423-(V8-900)	225-D2848-LE423,D2840-LE423,D2842-LE423-LE433,D2842-LE443-OM	8
	D2840-LE423-(V10-1100)		
	D2842-LE423-(V12-1360)		
	D2842-LE433-(V12-1550)		
	D2842-LE443-(V12-1224)		
226	D2842 LE620	226-D2842-LE620-OM	8
227	D2876 LE621	227-D2876-LE621-OM	8
228	D2876 LE423	228-D2876-LE423-OM	8
229	D0836 LE201	229-D0836-LE201-203-OM	8
	D0836 LE203		

230	D0834 LE101	230-D0834-LE101-102-OM	8
	D0834 LE102		
231	D2876 LE121	231-D2876-LE121-122-123-124-OM	8
	D2876 LE122		
	D2876 LE123		
	D2876 LE124		
232	D2876 LUE621	232-D2876-LUE621-622-623-OM	8
	D2876 LUE622		
	D2876 LUE623		
233	D0836 LE301	233-D0836-LE301-OM	8
234	D0836 LE423	234-D0836-LE423-OM	8
235	D2868 LE433	235-D2868-LE433,D2862-LE433-LE453-LE423-LE443-LE463-OM	8
	D2862 LE433		
	D2862 LE453		
	D2862 LE423		
	D2862 LE443		
	D2862 LE463		
	Bonus for MAN engine		
	Diesel attachment		
1	Pulse pickup - Assembly instructions		
2	Electronically controlled flame start system - Operation, Maintenance		
3	Seawater pump impeller - Installation, Maintenance		
4	Electric intake-air heater - Fitting instruction		
5	Metalastik "Cushy Float" engine mount		
6	Crankcase sealing parts - Assembly instructions		
7	Closure ball - Assembly instructions		
8	Main and thrust bearing caps - Installation instructions		
9	Crankshaft seal - Notes on assembly		
10	Magnetic-Speed-Adjuster - Setting Instructions		
11	Rapid flame start system - Operation, maintenance		
12	Electric coolant preheater - Assembly instructions		
13	Folder with Some drawings		
	Service record books		
14	Marine Diesel engines		
15	MAN engines for marine generating sets		
16	MAN marine Diesel engines for yachts, Common Rail		
17	MAN marine Diesel engines for yachts		
18	MAN marine Diesel engines for privately used yachts, "Gold Standard"		
19	MAN industrial Diesel engines		
20	Fuels, Lubricants and Coolants for MAN Diesel Engines		
	Installation instructions (useful information for repair)		
21	Installation instructions marine Diesel engines		
	<i>These Installation Instructions apply for the installation of MAN D 08 marine diesel engines with distributor injection pumps and D 28 engines with in-line injection pumps (not with common rail injection system), which have been designed and built for commercial shipping.</i>		
22	Installation Instructions, MAN Marine Diesel Engines Common Rail		
	<i>These Installation Instructions apply to the installation of D 28 Series marine diesel engines</i>		

	with common rail injection system.	
23	Installation Instructions, MAN industrial diesel engine.	
24	Allocation guideline values: starter system, battery value and starter cable for MAN high speed diesel engines all types	
25	Prestolite Handraulic Starter.	
26	CLEANING INSTRUCTIONS FOR SPARK ARRESTERS	
27	Maintenance Program of D 02 - and D 28 - diesel engines	
28	SERVICE INFORMATION NR. 66 Service intervals – control of injection nozzles	

Total:	852
Bulk order discount (70 %):	-596
Bulk Price Total:	256
Delivery (download):	0
<i>Bulk Price per book (31+35=66):</i>	3,87
Total Amount for payment USD:	256

Terms of payment: Prepayment with company order

All bank charges should be on remitter account (you have to point OUR in bank order).

Important remark: To avoid any delay with acceptance your payment please point in your bank instruction

1) Invoice number, 2) Date of Invoice 3) Technical Manuals.

Sample: Inv# 30, 01-Jun-2022, Tech manual.

Account for USD

Beneficiary: FOP Viktor Knyazyev
Name of the bank: PJSC CB "PRIVATBANK",
Bank Address: 1D HRUSHEVSKOHO STR., KYIV, 01001, UKRAINE.
SWIFT Code: PBANUA2X
IBAN (Bank account): UA703052990000026002034913056

Correspondent bank: JP Morgan Chase Bank, New York, USA
SWIFT Code: CHASUS33
Account: 001-1-000080
(for US customers: ABA ROUTING of JP Morgan Chase Bank # 021000021)

Account for EURO

Beneficiary: FOP Viktor Knyazyev
Name of the bank: PJSC CB "PRIVATBANK",
Bank Address: 1D HRUSHEVSKOHO STR., KYIV, 01001, UKRAINE.
SWIFT Code: PBANUA2X
IBAN (Bank account): UA653052990000026006044900033

Invoice may be paid by Visa or MasterCard (256 USD)

Via FONDY United Kingdom payment company (<http://fondy.eu>)

Via PayPal viktortechmanuals@gmail.com (privet account)

Via WU or MoneyGram.

See details on page: <http://engine.od.ua/payment>