

PERKINS DIESEL ENGINE MANUALS
BULK OFFER -SET # 45 - 1200 - 2000, 2300, V8 series

Spares - <http://brovertex.com> | Tech Library - <http://engine.od.ua> | Mariners support - <http://marengine.com>

Remarks: All free and Additional Manuals & Special Instructions, Technical Information Bulletins recommended by PERKINS for repair are included in FULL SET of documents.

OPERATION AND MAINTENANCE MANUAL / SERVICE (REPAIR) MANUALS					
<i>File (Media Number)</i>	<i>Series</i>	<i>Manual</i>	<i>Pages</i>	<i>Machine / Engine / Mechanism / Remarks</i>	<i>\$ Price</i>
KENR9115-01	1206E-E66-BK	Disassembly and Assembly	264	1206E-E66TA Industrial Engine. BK	\$18
KENR9114-01	1206E-E66-BK	Systems Operation Testing and Adjusting	96	1206E-E66TA Industrial Engine. BK	\$12
SEBU8603-01	1206E-E66-BK	Operation and Maintenance Manual	120	1206E-E66TA Industrial Engine. BK	\$8
KENR9113-01	1206E-E66-BK	Specification	56	1206E-E66TA Industrial Engine. BK	\$12
M0079540-01_EN	1206E-E70-BL	Troubleshooting	466	1206E-E70TTA Engines. BL	\$24
KENR9100-01	1206E-E70-BL	Disassembly and Assembly	296	1206E-E70TTA Industrial Engine. BL	\$18
SEBU8601-01	1206E-E70-BL	Operation and Maintenance Manual	134	1206E-E70TTA Industrial Engine. BL	\$8
KENR8799-01	1206E-E70-BL	Systems Operation Testing and Adjusting	104	1206E-E70TTA Industrial Engine. BL	\$12
KENR8798-01	1206E-E70-BL	Specification	56	1206E-E70TTA Industrial Engine. BL	\$12
UENR0677-00	1206F-E70TA-TTA	Disassembly and Assembly	334	1206F-E70TA and 1206F-E70TTA Industrial Engines. BM, BN	\$24
M0078202-00	1206F-E70TA-TTA	Special Instruction	4	Soot Antennae Check. Industrial Engine 1206F-E70TA (BM; BN)	\$1
SEBU8732-03	1206F-E70TA-TTA	Operation and Maintenance Manual	150	1206F-E70TA and 1206F-E70TTA Industrial Engines. BM, BN	\$8
UENR0683-06	1206F-E70TA-TTA	Troubleshooting	548	1206F-E70TA and 1206F-E70TTA Engines. BM, BN	\$28
M0087051-00_EN	1206F-E70TA-TTA	Special Instruction	4	Diesel Exhaust Fluid (DEF) Quality Sensor Updates on Certain 1206F-E70TA and 1206F-E70TTA Engines. BM, BN	\$1
UENR0676-00	1206F-E70TA-TTA	Systems Operation Testing and Adjusting	122	1206F-E70TA and 1206F-E70TTA Industrial Engines. BM, BN	\$14
UENR0675-00	1206F-E70TA-TTA	Specification	64	1206F-E70TA and 1206F-E70TTA Industrial Engines. BM, BN	\$12
M0075246-01_EN	1204E-1206E	Troubleshooting	340	1204E-E44TA, 1204E-E44TTA and 1206E-E66TA Engines. BK, MK, ML	\$24
REHS3769-00	1204E-1206E	Special Instruction	28	Assembly Requirements for Industrial 1206E-E70TTA (BL), 1206E-E66TA (BK), 1204E-E44T (MK;ML), 854E-E34TA (JR) Engines.	\$2
KENR9125-01	1204E-MK-ML	Disassembly and Assembly	290	1204E-E44TA , 1204E-E44TTA Industrial Engines. MK, ML	\$18
SEBU8605-01	1204E-MK-ML	Operation and Maintenance Manual	122	1204E-E44TA , 1204E-E44TTA Industrial Engines. MK, ML	\$8
KENR9124-01	1204E-MK-ML	Systems Operation Testing and Adjusting	104	1204E-E44TA , 1204E-E44TTA Industrial Engines. MK, ML	\$12

KENR9123-01	1204E-MK-ML	Specification	52	1204E-E44TA , 1204E-E44TTA Industrial Engines. MK, ML	\$12
M0075246-01_EN	1204E-MK-ML	Troubleshooting	340	1204E-E44TA, 1204E-E44TTA and 1206E-E66TA Engines. BK, MK, ML	\$24
REHS3769-00	1204E-MK-ML	Special Instruction	28	Assembly Requirements for Industrial 1206E-E70TTA (BL), 1206E-E66TA (BK), 1204E-E44T (MK;ML), 854E-E34TA (JR) Engines.	\$2
UENR4490-02	1204F-E44TA-TTA	Systems Operation Testing and Adjusting	132	1204F-E44TA and 1204F-E44TTA Industrial Engines. MT, MU, MW	\$14
UENR4469-19	1204F-E44TA-TTA	Troubleshooting	494	1204F-E44TA and 1204F-E44TTA Industrial Engines. MT, MU, MW	\$28
SEBU9063-03	1204F-E44TA-TTA	Operation and Maintenance Manual	144	1204F-E44TA and 1204F-E44TTA Industrial Engines. MT, MU, MW	\$8
UENR4491-00	1204F-E44TA-TTA	Disassembly and Assembly	302	1204F-E44TA and 1204F-E44TTA Industrial Engines. MT, MU, MW	\$18
UENR4489-00	1204F-E44TA-TTA	Specification	58	1204F-E44TA and 1204F-E44TTA Industrial Engines. MT, MU	\$12
REHS3771-02	1204F-E44TA-TTA	Special Instruction	54	Customer Assembly Requirements for 1206FE70TA, 1206F-E70TTA, 1204FE44TA, 1204F-E44TTA, and 854F-E34T Engines. Engine 1204F-E44TAA (MT; MU), 854F-E34T (JS; JT). Industrial Engine 1206F-E70TA (BM; BN)	\$8
TPD1352E4	1300-EDI	USER'S HANDBOOK	40	Perkins 1300 Series Edi Models WK to WS. Six cylinder, turbocharged, diesel engines with an electronic management system for industrial and agricultural applications	\$8
TPD1353E3	1300-EDI	WORKSHOP MANUAL	264	Perkins Peregrine EDi and 1300 Series Edi Models WK to WS	\$20
TPD1303EFG	1300-WB-WC	USER'S HANDBOOK	65	1300 Series. Six cylinder diesel engines for industrial and agricultural applications.	\$8
TPD1307E	1300-WB-WC	WORKSHOP MANUAL	310	Peregrine-Six cylinder diesel engines for automotive applications. 1300 series-Six cylinder diesel engines for industrial and agricultural applications	\$12
TPD1315E6	1300-WD-WJ	USER'S HANDBOOK	44	Perkins 1300 Series Models WF to WJ	\$8
TPD1347E2	1300-WD-WJ	WORKSHOP MANUAL	198	Perkins Peregrine and New Generation 1300 Series Models WD to WJ	\$18
TPD1314E4	1300-WG-WJ	USER'S HANDBOOK	44	Perkins Peregrine Models WG and WJ. Six cylinder turbocharged diesel engines for automotive applications.	\$8
TPD1360E2	1300-WL-WS	USER'S HANDBOOK	42	Perkins Peregrine Edi Models WL, WN, WQ, and WS. Six cylinder, turbocharged, diesel engines with an electronic management system for automotive applications	\$8
TPD1404E1	1300-EDi-Electrical	Special Instruction	24	The 1300 series Edi. Electrical Installation Guide	\$2

UENR4510-02	1500	Systems Operation Testing and Adjusting	82	1506A-E88TA, 1506C-E88TA and 1506D-E88TA Industrial Engines. LG, PK9	\$12
UENR4512-03	1500	Troubleshooting	256	1506A-E88TA, 1506C-E88TA and 1506D-E88TA Industrial Engines. LG, PK9	\$18
SEBU9070-01	1500	Operation and Maintenance Manual	112	1506A-E88TA, 1506C-E88TA and 1506D-E88TA Industrial Engines. LG, PK9	\$8
UENR4509-01	1500	Specification	48	1506A-E88TA, 1506C-E88TA and 1506D-E88TA Industrial Engines. LG, PK9	\$12
UENR4540-00	1500	Schematic	2	1506D Industrial Engines Electrical System. PK9	\$2
UENR4511-01	1500	Disassembly and Assembly	180	1506A-E88TA, 1506C-E88TA and 1506D-E88TA Industrial Engines. LG, PK9	\$18
UENR4451-00	1500	Schematic	2	1506A and C Industrial Engines Electrical System. LG	\$2
KENR8773-00	1600	Disassembly and Assembly	212	1600 Series Industrial Engine. XGA, XGB, XGD, XGE, XGF, XGH	\$18
KENR8775-00	1600	Schematic	2	1600 Series Industrial Engine Electrical System. XGA, XGB, XGD, XGE, XGF, XGH	\$2
SEBU8455-00	1600	Operation and Maintenance Manual	92	1600 Series Industrial Engine. XGA, XGB, XGD, XGE, XGF, XGH	\$8
KENR8772-00	1600	Systems Operation Testing and Adjusting	92	1600 Series Industrial Engine. XGA, XGB, XGD, XGE, XGF, XGH	\$12
KENR8771-00	1600	Specification	44	1600 Series Industrial Engine. XGA, XGB, XGD, XGE, XGF, XGH	\$12
KENR8774-00	1600	Troubleshooting	202	1600 Series Industrial Engine. XGA, XGB, XGD, XGE, XGF, XGH	\$18
TSD3215E12	2000	USER'S HANDBOOK	64	Perkins 2000 Series. All 2000 diesel models. 6 cylinder diesel engines for industrial applications	\$8
TSD3409E4	2000	USER'S HANDBOOK	50	Perkins 2000 Series Models 2006SI and 2006TSI. 6 cylinder (gas) spark ignited engines for industrial applications.	\$8
TPD3245E2	2000	WORKSHOP MANUAL	194	Perkins 2000 Series. 6 cylinder diesel engines for industrial applications	\$18
TSD3244E	2000-Eagle	USER'S HANDBOOK	53	Perkins Eagle TX and Eagle 800 6 cylinder diesel engine for Truck	free
TSD3429E3	2000-Eagle	USER'S HANDBOOK	50	Eagle Tx2000	free
TSD3433E1	2000-Eagle	WORKSHOP MANUAL	132	Eagle 800, Eagle Tx, Eagle Tx2000	\$8
SEBU9072-00	2206D-E13TA	Operation and Maintenance Manual	90	2206D-E13TA Industrial Engine. PK3	\$8
UENR0631-00	2206D-E13TA	Specification	42	2206D-E13TA Industrial Engine. PK3	\$12
UENR0632-00	2206D-E13TA	Systems Operation Testing and Adjusting	64	2206D-E13TA Industrial Engine. PK3	\$12
UENR4541-00	2206D-E13TA	Schematic	2	2206D Industrial Engines Electrical System. PK3	\$2

Terms of payment: Prepayment with company order

PAYMENT WAYS:

See details on <https://engine.od.ua/payment>

or in [PDF file](#)