$\begin{array}{c} \text{INSTRUCTION BOOK} \\ \text{VOLUME } \Pi \end{array}$

Engine type L27/38

 ▲ Hyundai Heavy Industries Co., Ltd. Engine & Machinery Division
 1, Cheonha-Dong, Dong-Ku, Ulsan, Korea http:// www.hhi.co.kr
 http:// as.hyundai-engine.com

Engine After Service Dept. TEL : (82) 52-230-7412~20 FAX : (82) 52-230-7581 (82) 52-250-9841 E-mail : engineas@hhi.co.kr Engine Parts Sales Dept. TEL : (82) 52-230-7311~20 FAX : (82) 52-230-7582

E-mail : eservice@hhi.co.kr

This book must in no case be wholly or partially copied and published or passed to unauthorized persons without the permission of HYUN-DAI HEAVY INDUSTRIES CO., LTD. ENGINE & MACHINERY DIVISION.

L27/38

Operation of Engine (Ploto no. 501)	Applied : Not applied
Operation of Engine (Plate no. 501)	
501-1. Operationa) Woodward made	- 501.01 Ed.11H
b) Europa made	· 501.01 Ed.08H
Trouble Tracing (Plate no. 503)	
503-1. Trouble Shooting Guide for Air Starter a) Gali made	- 503.06 Ed.06H
b) TDI made	503.06 Ed.05H
Cylinder Head (Plate no. 505)	
505-1. Cylinder Head a) Two piece sleeve	50501-05E1
b) One piece sleeve	50501-05E
Control and Safety Systems (Plate no. 509)	
509-1. Governor and Governor Drive a) Woodward made	· 501.01 Ed.11H
b) Europa made	501.01 Ed.08H
509-2. Manual for Governor a) Woodward made (UG 15D)	
b) Europa made	
Crankshaft and Main Bearings (Plate no. 510)	
510-1. Vibration Dampera) Geislinger made	510-04.00 Ed.06H
b) Vulkan made	510-04.00 Ed.04H
510-2. Vibration Damper with Attachmenta) Geislinger made	51004-07H
b) Vulkan made	51004-05H

Turbocharger system (Plate no. 512)

512-1. Manual for Turbocharger

- a) NR20/S (FOR 5,6L27/38)
- b) NR24/S (FOR 7,8L27/38)
- c) NR29/S (FOR 9L27/38)

Compressed Air System (Plate no. 513)

	513-1. Overhaul, Test and Inspection of Air Starter	
	a) Gali made	
	b) TDI made	513-01.30 Ed.04H
	513-2. Turning Gear	
	a) Manual turning gear	
	b) Electric turning gear	513-25.00 Ed.01H
	513-3. Air Starter	54000 4411
	a) Gali made (Starter serial no. > 02-0101)	51309-11H 51309-13H
	b) TDI made	
L]	for Output gear ratio 11.7 : 1	
	for Output gear ratio 9.25 : 1	51309-10H
	513-4. Main Starting Valve (* If selected 513-3,b)	51310-03H
	513-5. Turning Gear	
	a) Turning gear with attachment	51325-03E
	b) Electric turning gear	51325-05H
	Fuel Oil System (Plate no. 514)	
	514-1. Fuel Oil Safety Filter	51415-01H
	Lubricating Oil System (Plate no. 515)	
	515-1. Centrifugal by-pass filter	515-15.00 Ed.04H
		51515-03H
	Special equipment (Plate no. 517)	
	517-1. Flexible coupling	
	517-2. Air motor pump unit for emergency start	
	517-3. Oil mist detector(Schaller VN115) 517-4. L.O. Auto back-flushing filter	