

# CONTENTS

## Hyundai Crawler Excavator Robex R160LC-3

Page	Contents	Serial_No	Revision_No
<b>1</b>	<b>ENGINE</b>		
1010	ENGINE MOUNTING		2001. 6.10 REV.8
1020	FUEL SYSTEM		2000. 8. 5 REV.6
1030	COOLING SYSTEM 1		2002. 8.31 REV.10
1031	COOLING SYSTEM 2		2000. 8. 5 REV.6
1040	AIR INTAKE SYSTEM		2004. 2.23 REV.99
1050	EXHAUST SYSTEM		2003. 5.31 REV.11
1060	ENGINE CONTROL SYSTEM		2001. 1.15 REV.7
1070	FUEL TANK		2003. 5.31 REV.11
<b>2</b>	<b>HYDRAULIC SYSTEM</b>		
2010	PUMP MOUNTING		
2020	MAIN PUMP		
2021	REGULATOR		
2022	GEAR PUMP		
2030	HYDRAULIC TANK		2003. 5.31 REV.11
2040	UPPER HYDRAULIC PIPING(BASE)		2003. 5.31 REV.11
2041	UPPER HYDRAULIC PIPING(ATTACH)		'98.10.20 REV.1
2042	UPPER HYDRAULIC PIPING(TRAVEL)		2001. 1.15 REV.7
2043	DOZER BLADE HYDRAULIC PIPING 1		2001. 1.15 REV.7
2044	DOZER BLADE HYDRAULIC PIPING 2		'99. 9.20 REV.3
2045	DOZER CONTROL VALVE(#0125-)	#0125 -	2003. 5.31 REV.11
2050	PILOT HYDRAULIC PIPING(BASE 1)		2004. 2.23 REV.99
2051	PILOT HYDRAULIC PIPING(BASE 2)		2001.12.31 REV.9
2052	PILOT HYDRAULIC PIPING(BASE 3)		'99. 9.20 REV.3
2053	PILOT HYDRAULIC PIPING(CNTL 1)		2003. 5.31 REV.11
2054	PILOT HYDRAULIC PIPING(CNTL 2)		2003. 5.31 REV.11
2055	PILOT HYDRAULIC PIPING(CNTL 3)		'99. 9.20 REV.3
2056	SOLENOID VALVE		2001. 6.10 REV.8
2060	TRAVEL HYD PIPING(-#0241)	- #0241	2002. 8.28 REV.99
2060A	TRAVEL HYD PIPING(#0242-)	#0242 -	2002. 8.28 REV.99
2061	TRAVEL HYD PIPING(R160LCD-3, -#0241)	- #0241	2002. 8.28 REV.99
2061A	TRAVEL HYD PIPING(R160LCD-3, #0242-)	#0242 -	2002. 8.28 REV.99
2065	TRAVEL HYD PIPING(#0395-, EU ONLY)	#0395 - #0411	2002. 8.28 REV.99
2070	BOOM HYDRAULIC PIPING(5.1M)		'99. 9.20 REV.3
2080	ARM HYDRAULIC PIPING(2.25M)		2003. 5.30 REV.99
2081	ARM HYDRAULIC PIPING(2.6M)		2003. 5.30 REV.99
2082	ARM HYDRAULIC PIPING(3.1M)		2003. 5.30 REV.99
2090	BOOM GREASE LUB SYSTEM(5.1M)		
2100	MAIN CONTROL VALVE(1/2)		2003. 5.31 REV.11
2101	MAIN CONTROL VALVE(2/2)		2003. 5.31 REV.11
2110	SWING MOTOR		
2111	SWING REDUCTION GEAR		
2120	REMOTE CONTROL LEVER		2003. 5.31 REV.11
2121	REMOTE CONTROL LEVER(#0392-)	#0392 -	2001. 1.15 REV.7
2130	REMOTE CONTROL PEDAL		
2140	TURNING JOINT		
2141	TURNING JOINT(R160LCD-3)		2000. 8. 5 REV.6
2150	TRAVEL MOTOR(1/2, -#0241)	- #0241	'99.12.20 REV.4
2151	TRAVEL MOTOR(2/2, -#0241)	- #0241	'99.12.20 REV.4
2152	TRAVEL REDUCTION GEAR(-#0241)	- #0241	'99.12.20 REV.4
2153	TRAVEL MOTOR(1/2, #0395-, EU ONLY)	#0395 -	2003. 5.31 REV.11
2153A	TRAVEL MOTOR(2/2, #0395-, EU ONLY)	#0395 -	2003. 5.31 REV.11
2154	TRAVEL REDUCTION GEAR(#0395-, EU ONLY)	#0395 -	2003. 5.31 REV.11
2155	TRAVEL MOTOR(1/3, #0242-)	#0242 -	2003. 5.31 REV.11
2156	TRAVEL MOTOR(2/3, #0242-)	#0242 -	2003. 5.31 REV.11
2157	TRAVEL MOTOR(3/3, #0242-)	#0242 -	2003. 5.31 REV.11
2158	TRAVEL REDUCTION GEAR(#0242-)	#0242 -	2003. 5.31 REV.11
2160	BOOM CYLINDER		2000. 8. 5 REV.6
2170	ARM CYLINDER		2004. 3.09 REV.99

2180	BUCKET CYLINDER		
2190	DOZER BLADE CYLINDER		'98.10.20 REV.1
2200	BOOM SAFETY LOCK SYSTEM(-#0286)	- #0286	2000. 8. 5 REV.6
2200A	BOOM SAFETY LOCK SYSTEM(#0287-)	#0287 -	2000. 8. 5 REV.6
2201	BOOM SAFETY LOCK VALVE(#0165-)	#0165 -	2001. 1.15 REV.7
2210	ARM SAFETY LOCK SYSTEM(-#0286)	- #0286	2000. 8. 5 REV.6
2210A	ARM SAFETY LOCK SYSTEM(#0287-)	#0287 -	2004. 3.09 REV.99
2211	ARM SAFETY LOCK VALVE(#0165-)	#0165 -	2001. 1.15 REV.7
2220	SINGLE ACTING HYD PIPING KIT 1		2003.10.20 REV.99
2221	SINGLE ACTING HYD PIPING KIT 2		2003.10.20 REV.99
2222	SINGLE ACTING MAIN PIPING(-#0308)	- #0308	2000. 8. 5 REV.6
2222A	SINGLE ACTING MAIN PIPING(#0309-)	#0309 -	2003.11.18 REV.99
2223	ATTACH PIPING(S/ACTING, -#0308)	- #0308	2000. 8. 5 REV.6
2223A	ATTACH PIPING(S/ACTING, #0309-)	#0309 -	2003.10.30 REV.99
2224	DOUBLE ACTING HYD PIPING KIT		2003.10.20 REV.99
2225	DOUBLE ACTING MAIN PIPING(-#0235)	- #0235	'99.12.20 REV.4
2225A	DOUBLE ACTING MAIN PIPING(#0236-#0241)	#0236 - #0241	2000. 8. 5 REV.6
2225B	DOUBLE ACTING MAIN PIPING(#0242-)	#0242 -	2003.11.18 REV.99
2226	DOUBLE ACTING BOOM PIPING(-#0241)	- #0241	2000. 8. 5 REV.6
2227	DOUBLE ACTING ARM PIPING(-#0241)	- #0241	2000. 8. 5 REV.6
2227A	ATTACH PIPING(D/ACTING, #0242-)	#0242 -	2003.10.30 REV.99
2228	SINGLE PEDAL(DOUBLE ACTING)		'99. 2.28 REV.2
<b>3</b>	<b>ELECTRIC SYSTEM</b>		
3010	ELECTRIC PARTS 1		2001. 6.10 REV.8
3011	ELECTRIC PARTS 2		2001. 6.10 REV.8
3012	ELECTRIC PARTS 3		2001. 6.10 REV.8
3020	TOOL BOX ELECTRIC PARTS		2000. 3.25 REV.5
3021	FUEL FILLER PUMP(-#0241)	- #0241	2001. 6.10 REV.8
3022	FUEL FILLER PUMP(#0242-)	#0242 -	2003. 5.31 REV.11
3030	CAB ELECTRIC 1		2001.12.31 REV.9
3031	CAB ELECTRIC 2		2002. 8.31 REV.10
3040	CONTROL PANEL		2004.04.06 REV.99
3050	ELECTRIC BOX ASSY		2001. 6.10 REV.8
3060	AIR CONDITIONER & HEATER MOUNTING		2003. 5.31 REV.11
3061	HEATER & EVAPORATOR UNIT		2001. 6.10 REV.8
3070	AIR CONDITIONER MOUNTING		2003. 5.31 REV.11
3071	EVAPORATOR UNIT		2001. 6.10 REV.8
3080	HEATER MOUNTING		2003. 5.31 REV.11
3081	HEATER UNIT		2001. 6.10 REV.8
<b>4</b>	<b>UPPER STRUCTURE</b>		
4010	UPPER FRAME & COUNTERWEIGHT		2002. 8.31 REV.10
4020	COWLING 1		2002. 8.31 REV.10
4021	COWLING 2		2002. 8.31 REV.10
4022	COWLING 3		2002. 8.31 REV.10
4023	COWLING 4		'99. 9.20 REV.3
4024	COWLING 5		2002. 8.31 REV.10
4025	COWLING 6		'99. 9.20 REV.3
4030	ENGINE HOOD		2002. 8.31 REV.10
4040	UNDER COVER		2001. 6.10 REV.8
4050	CAB MOUNTING		2003. 5.31 REV.11
4060	CAB ASSY(1/3)		2003. 5.31 REV.11
4061	CAB ASSY(2/3)		2003. 5.31 REV.11
4062	CAB ASSY(3/3, DOOR)		2005.10.31 REV.99
4070	CAB INTERIOR 1		2001.12.31 REV.9
4071	CAB INTERIOR 2		'99. 9.20 REV.3
4072	BOTTOM PLATE MOUNTING		2003. 5.31 REV.11
4073	CONSOLE BOX		'99. 9.20 REV.3
4074	SEAT(-#0434)	- #0434	2003. 5.31 REV.11
4075	SEAT(#0435-#0529)	#0435 - #0529	2004.02.26 REV.99
4076	SEAT(#0530-)	#0530 -	2004.02.26 REV.99
4080	TOOL BOX MOUNTING		'99. 9.20 REV.3
4081	TOOL BOX		2000. 3.25 REV.5
4090	SWING RING GREASE LUB SYSTEM		2002. 8.31 REV.10
4100	VANDALISM COVER(A/VANDAL CAB)		
<b>5</b>	<b>LOWER STRUCTURE</b>		

5010	LOWER FRAME		2002. 8.31 REV.10
5020	LOWER COVER GROUP		2003. 5.31 REV.11
5030	LOWER ROLLER		2001. 6.10 REV.8
5040	UPPER ROLLER		
5050	IDLER		2001.12.31 REV.9
5060	ADJUST COMPONENT		2002. 8.31 REV.10
5070	TRACK CHAIN		2000. 3.25 REV.5
5080	DOZER BLADE(R160LCD-3)		'99. 9.20 REV.3
<b>6</b>	<b>ATTACHMENT</b>		
6010	BOOM MOUNTING(-#0183)	- #0183	'99. 9.20 REV.3
6011	BOOM MOUNTING(#0184-)	#0184 -	'99. 9.20 REV.3
6020	BOOM(5.1M, STD)		2001. 6.10 REV.8
6030	ARM(2.6M, STD)		2001.12.31 REV.9
6031	ARM(2.25M, SUPER SHORT)		2001.12.31 REV.9
6032	ARM(3.1M, SUPER LONG)		2001.12.31 REV.9
6040	BUCKET CONTROL GROUP		'99. 2.28 REV.2
6050	BUCKET(0.65M3 PCSA HEAPED, STD)		
6051	BUCKET(0.39M3 PCSA HEAPED, NARROW)		'98.10.20 REV.1
6052	BUCKET(0.57M3 PCSA HEAPED, NARROW)		'98.10.20 REV.1
6053	BUCKET(0.70M3 PCSA HEAPED, NARROW)		'98.10.20 REV.1
6054	BUCKET(0.80M3 PCSA HEAPED, LIGHT DUTY)		'98.10.20 REV.1
6055	BUCKET(0.69M3 PCSA HEAPED, HEAVY DUTY)		'99. 9.20 REV.3
<b>7</b>	<b>OTHERS</b>		
7010	TOOLS		2000. 8. 5 REV.6
7020	DECALS		2002. 8.31 REV.10
7040	RECOMMEND SPARE PARTS KIT		2003.11.25 REV.99
<b>8</b>	<b>ENGINE BASE</b>		
8010	FRONT DRIVE ADAPTER		
8020	AIR INTAKE HEATER		
8030	DATAPLATE		
8040	ROCKER LEVERS		
8050	VALVE TAPPET		
8060	CYLINDER BLOCK		
8070	CRANKSHAFT AND MAIN BEARING		
8080	FRONT GEAR COVER		
8090	CAM FOLLOWER COVER		
8100	FRONT GEAR TRAIN ACC DRIVE		
8110	FUEL DRAIN LOCATION		
8120	THERMOSTAT		
8130	ALTERNATOR LOCATION 1		
8140	ALTERNATOR LOCATION 2		
8150	MECHANICAL TACHOMETER DRIVE		
8160	FAN DRIVE 1		
8170	FAN DRIVE 2		
8180	AIR FUEL CONTROL PLUMBING		
8190	FUEL FILTER		
8200	FUEL FILTER PLUMBING		
8210	FLYWHEEL HOUSING		
8220	BASE FUEL PUMP		
8230	FUEL PUMP COUPLING		
8240	FUEL SYSTEM ACCESSORIES 1		
8250	FUEL SYSTEM ACCESSORIES 2		
8260	FUEL PLUMBING		
8270	FUEL SHUTOFF VALVE		
8280	FLYWHEEL		2001. 6.10 REV.8
8290	LIFTING BRACKET		
8300	LUBRICATING OIL COOLER		
8310	OIL LEVEL GAUGE 1		
8320	OIL LEVEL GAUGE 2		
8330	LUBRICATING OIL PUMP		
8340	CYLINDER BLOCK COVER 1		
8350	CYLINDER BLOCK COVER 2		
8360	OIL PAN 1		
8370	OIL PAN 2		
8380	CONNECTING ROD AND PISTON		

8390	CAMSHAFT		
8400	FUEL INJECTOR		
8410	CYLINDER HEAD		
8420	TURBOCHARGER 1		
8430	TURBOCHARGER 2		
8440	CYLINDER HEAD GASKET		
8450	STARTING MOTOR MOUNTING		
8455	STARTING MOTOR(#0416-)	#0416 -	2001. 6.10 REV.8
8460	FAN PILOT SPACER 1		
8470	FAN PILOT SPACER 2		
8480	TURBOCHARGER LOCATION		
8490	THERMOSTAT HOUSING		
8500	TURBOCHARGER LOCATION		
8510	VALVE COVER		
8520	AFTERCOOLER PLUMBING		
8530	ENGINE VENT PLUMBING		
8540	WATER INLET CONNECTION 1		
8550	WATER INLET CONNECTION 2		
8560	WATER PUMP		
8570	EXHAUST PLUMBING		