

MAN Diesel A/S • Denmark



Service Letter

SL07-488/PMN November 2007

# Work Inside Cylinder Liners

Action Code: IMMEDIATELY

**Dear Sirs** 

We regret very much having to inform you about an accident that occurred recently on a vessel in Bremerhaven.

During modification work inside the cylinder liner on a K90MC engine, only the exhaust valve had been removed to allow access into the cylinder liner. One fitter was inside the liner when cooling water was admitted by accident, see Encl. 1.

The cooling water entered the combustion chamber from the bores in the cylinder cover, where cooling water passes from the cylinder cover to the exhaust valve. Further to normal precautious practices and safety procedures, we therefore stress the following:

#### <u>Risks</u>

A number of risks must be taken into account when a person enters a restricted working space, such as the combustion chamber:

• Exhaustion/fatigue

Due to the high temperature of the cylinder liner surface, the piston crown and the cylinder cover, and combined with restricted air circulation, the air temperature can reach 50 to 60 degrees Celsius.

The exhaustion of the human body in this environment can cause a collapse, and it is difficult to transport a collapsed person out through the small opening in the top.

HEAD OFFICE (& postal address) MAN Diesel A/S Teglholmsgade 41 2450 Copenhagen SV Denmark Phone: +45 33 85 11 00 Fax: +45 33 85 10 30 mandiesel-cph@mandiesel.com www.mandiesel.com PrimeServ Teglholmsgade 41 2450 Copenhagen SV Denmark Phone: +45 33 85 11 00 Fax: +45 33 85 10 49 PrimeServ-cph@mandiesel.com PRODUCTION Teglholmsgade 35 2450 Copenhagen SV Denmark Phone: +45 33 85 11 00 Fax: +45 33 85 10 17 manufacturing-dk@mandiesel.com 
 FORWARDING & RECEIVING
 MAN Diesel A/S

 Teglholmsgade 35
 Denmark

 2450 Copenhagen SV
 Reg. No.: 39661314

 Denmark
 Phone: +45 33 85 11 00

 Fax:
 +45 33 85 10 16

### MAN Diesel



Cooling water

Opening the cooling water inlet cock to the cylinder unit will cause approximately 80 degrees Celsius hot cooling water to enter, with severe consequences for a person working inside.

Fire

In case of an engine room fire, the person inside the cylinder liner cannot escape without help from outside.

#### Precautions to be taken

For any work, inspection or cleaning inside a cylinder liner, the cylinder cover **must** always be removed before entering. A cylinder liner should never be entered by only removing the exhaust valve and gain access by either standing on the piston and turning, or by climbing down a ladder through the bore in the cylinder cover.

A safety assistant **must**, at all times, be present outside the cylinder liner and be in constant contact with the person working inside the cylinder liner.

A ladder **must** be present in order for the person inside the liner to be able to escape even in the event of a power failure.

Basic safety guidelines

- During work in an engine room it is essential to <u>follow basic safety guidelines</u> as outlined in our Operation manual, section 701-01 Safety Precautions.
- Before entering restricted spaces such as cylinder liners, scavenge air receivers, crankcases, etc., take the following safety precautions:
  - Plan for escape exit by opening all covers
  - o Prepare ladders and/or wear safety harness
  - Always place a safety assistant outside who is in contact with the person inside the restricted space.

Be aware that the noisy environment in an engine room makes communication very difficult and can lead to misunderstandings.

Questions or comments regarding this SL should be directed to our Dept. AE-CPH.

Yours faithfully MAN Diesel A/S

Peter Michael Nielsen

Otto Winkel

Encl.

## **MAN Diesel**



Encl. 1 for SL07-488/PMN

# Person working inside a cylinder liner with cylinder cover mounted

