


Technical (Service / Workshop) Manuals



Technical (Service / Workshop) Manuals

Model	Technical Manual
Carbureted Gasoline Generators	
3.0 BPMG - 50 Hz	Technical Manual 052089
3.0 BPMG - 50 Hz Fresh Water-Cooled	Technical Manual 052089
3.0 BPMG - 60 Hz	Technical Manual 052089
3.0 BPMG - 60 Hz Fresh Water-Cooled	Technical Manual 052089
3.5 BCG - 50 Hz	Technical Manual 038747
3.75 BCGB - 50 Hz	Technical Manual 044898
3.75 BCGTC - 50 Hz	Technical Manual 044518
3.75 BCGTE - 50 Hz	Technical Manual 044518
4.0 BCG	Technical Manual 036209
4.2 BCG Low-Profile - 50 Hz	Technical Manual 052020
4.2 BCGA Low-Profile - 50 Hz	Technical Manual 052020
4.5 BCG	Technical Manual 038747
4.5 BCGB	Technical Manual 044898
4.5 BCGTC	Technical Manual 044518
4.5 BCGTE	Technical Manual 044518
4.8 BCG - 50 Hz	Technical Manual 036209
4.9 TWG - 50 Hz	Technical Manual 034645
5.0 BCG - 50 Hz	Technical Manual 038747
5.0 BCG Low-Profile	Technical Manual 052020
5.0 BCGA Low-Profile	Technical Manual 052020
5.0 BCGB - 50 Hz	Technical Manual 044898
5.8 BCGC Low-Profile - 50 Hz	Technical Manual 052020
5.8 BCGD Low-Profile - 50 Hz	Technical Manual 052020
6.0 BCGTC - 50 Hz	Technical Manual 044518
6.0 BCGTE - 50 Hz	Technical Manual 044518
6.0 TWG - 50 Hz	Technical Manual 034645
6.4 BEG - 50 Hz	Technical Manual 044240
6.5 BCG	Technical Manual 036209
6.5 TWG	Technical Manual 034645
6.8 BTG - 50 Hz	Technical Manual 037375
7.0 BCG	Technical Manual 038747
7.0 BCGA - 60 Hz Only	Technical Manual 038747
7.0 BCGB	Technical Manual 044898
7.0 BCGC Low-Profile	Technical Manual 052020
7.0 BCGD Low-Profile	Technical Manual 052020
7.0 BTG - 50 Hz	Technical Manual 036209
7.2 BCGTC	Technical Manual 044518
7.2 BCGTE	Technical Manual 044518
8.0 BCGTC - 50 Hz	Technical Manual 044518
8.0 BCGTE - 50 Hz	Technical Manual 044518
8.0 BEG - 50 Hz	Technical Manual 044240
8.0 BEG - 60 Hz	Technical Manual 044240
8.0 TWG	Technical Manual 034645
8.5 BTG	Technical Manual 037375
9.0 BTG	Technical Manual 036209
9.6 BCGTC	Technical Manual 044518

9.6 BCGTE	Technical Manual 044518
10.0 BEG	Technical Manual 044240
10.0 BEG - 50 Hz	Technical Manual 044240
10.0 BTG - 50 Hz	Technical Manual 037375
11.0 TWG	Technical Manual 034645
12.0 BEG - 50 Hz	Technical Manual 044240
12.0 BTG - 50 Hz	Technical Manual 037375
12.5 BEG	Technical Manual 044240
12.5 BTG	Technical Manual 037375
15.0 BEG	Technical Manual 044240
15.0 BTG	Technical Manual 037375
16.0 BEG - 50 Hz	Technical Manual 048088
20.0 BEG	Technical Manual 048088
20.0 BEG - 50Hz	Technical Manual 048088
25.0 BEG	Technical Manual 048088
Century Engines	
Century 80-N4	Technical Manual 047069
Century 110-T4	Technical Manual 047069
Century 120-N6	Technical Manual 047069
Century 170-T6	Technical Manual 047069
Climate Control	
10,000 BTU	Rotary Aire Operator's-Technical-Parts Manual 050259
17,000 BTU	Rotary Aire Operator's-Technical-Parts Manual 050259
Diesel Generators	
2.4 WMD - 50 Hz	Technical Manual 033403
3.0 WMD	Technical Manual 033403
3.3 BCD - 50 Hz	Technical Manual 043444
3.3 WMD - 50 Hz	Technical Manual 043444
4.0 BCD - 50 Hz	Technical Manual 038673
4.0 BCDA - 60 Hz Only	Technical Manual 038673
4.0 BCDB - 50 Hz	Technical Manual 038673
4.4 BCD	Technical Manual 043444
4.4 WMD	Technical Manual 043444
4.5 BCD - 50 Hz	Technical Manual 043444
4.5 WMD - 50 Hz	Technical Manual 043444
5.0 BCD - 60 Hz	Technical Manual 038673
5.0 BCDA	Technical Manual 038673
5.0 BCDB	Technical Manual 038673
5.0 BTD - 50 Hz	Technical Manual 038673
5.5 BCD	Technical Manual 038673
5.7 BTD - 50 Hz	Technical Manual 038673
5.8 WMD - 50 Hz	Technical Manual 043444
6.0 BCD	Technical Manual 043444
6.0 BTD - 50 Hz	Technical Manual 043444
6.0 BTDA - 50 Hz	Technical Manual 045100
6.0 WMD	Technical Manual 043444
6.0 WMD - 50 Hz	Technical Manual 043444
6.5 BTD	Technical Manual 038673

7.5 BTD - 50 Hz	Technical Manual 043444
7.5 BTDA - 50 Hz	Technical Manual 045100
7.6 BTD	Technical Manual 038673
7.7 WMD	Technical Manual 043444
8.0 BTD	Technical Manual 043444
8.0 BTDA	Technical Manual 045100
8.0 WMD	Technical Manual 043444
8.3 BTD - 50 Hz	Technical Manual 043440
8.3 WMD - 50 Hz	Technical Manual 043440
8.8 BTDB - 50 Hz	Technical Manual 045100
9.2 BTD - 50 Hz	Technical Manual 045100
9.4 BTDA - 50 Hz	Technical Manual 043440
9.4 BTDB - 50 Hz	Technical Manual 045100
9.4 WMD - 50 Hz	Technical Manual 043440
10.0 BTD	Technical Manual 043444
10.0 BTDA	Technical Manual 045100
10.4 BTD - 50 Hz	Technical Manual 045100
11.0 BTD	Technical Manual 043440
11.0 BTDB	Technical Manual 045100
11.0 WMD	Technical Manual 043440
11.5 BTD	Technical Manual 045100
12.0 BTDA - 50 Hz	Technical Manual 032460
12.0 BTDB - 50 Hz	Technical Manual 032460
12.0 BTDC - 50 Hz	Technical Manual 045100
12.0 WTA - 50 Hz	Technical Manual 032460
12.5 BTD - 60 Hz	Technical Manual 043440
12.5 BTDA	Technical Manual 043440
12.5 BTDB	Technical Manual 045100
12.5 WMD	Technical Manual 043440
12.6 BTD	Technical Manual 045100
15.0 BTDA	Technical Manual 032460
15.0 BTDB	Technical Manual 032460
15.0 BTDC	Technical Manual 045100
15.0 WTA - 60 Hz	Technical Manual 032460
16.0 BED - 50 Hz	Technical Manual 043317
16.0 BEDA - 50 Hz	Technical Manual 043317
16.0 WTA - 50 Hz	Technical Manual 024331
20.0 BED - 50 Hz	Technical Manual 040485
20.0 BED - 60 Hz	Technical Manual 043317
20.0 BEDA	Technical Manual 043317
20.0 WMF - 50Hz	Technical Manual 033355
20.0 WTA - 50Hz	Technical Manual 033355
20.0 WTA - 60 Hz	Technical Manual 024331
25.0 BED - 60 Hz	Technical Manual 040485
25.0 BEDA - 50 Hz	Technical Manual 043750
25.0 WMF - 50 Hz	Technical Manual 033355
25.0 WMF - 60 Hz	Technical Manual 033355
25.0 WTA - 60 Hz	Technical Manual 033355
26.0 WTA	Technical Manual 033355
32.0 BEDA	Technical Manual 043750

32.0 WMF - 60 Hz	Technical Manual 033355
Century 35.0 BED - 50 Hz	Technical Manual 047069
Century 45.0 BED - 50 Hz	Technical Manual 047069
Century 45.0 BED - 60 Hz	Technical Manual 047069
Century 55.0 BED - 50 Hz	Technical Manual 047069
Century 55.0 BED - 60 Hz	Technical Manual 047069
Century 65.0 BED	Technical Manual 047069
Century 80.0 BED - 50 Hz	Technical Manual 047069
Century 95.0 BED	Technical Manual 047069
Electronic Diesel Generators	
5.0 EDC D-NET - 50 Hz	Technical Manual 054560
5.0 EDT D-NET - 50 Hz	Technical Manual 054560
5.5 EDC D-NET	Technical Manual 054560
5.7 EDT D-NET - 50 Hz	Technical Manual 054560
6.0 EDT D-NET - 50 Hz	Technical Manual 054600
6.5 EDT D-NET	Technical Manual 054560
7.5 EDT D-NET - 50 Hz	Technical Manual 054600
7.6 EDT D-NET	Technical Manual 054560
8.0 EDT D-NET	Technical Manual 054600
8.8 EDT D-NET - 50 Hz	Technical Manual 054600
9.2 EDT D-NET - 50 Hz	Technical Manual 054600
9.4 EDT D-NET - 50 Hz	Technical Manual 054600
10.0 EDT D-NET	Technical Manual 054600
10.4 EDT D-NET - 50 Hz	Technical Manual 054600
11.0 EDT D-NET	Technical Manual 054600
11.5 EDT D-NET	Technical Manual 054600
12.0 EDT D-NET - 50 Hz	Technical Manual 054600
12.5 EDT D-NET	Technical Manual 054600
12.6 EDT D-NET	Technical Manual 054600
13.5 EDE D-NET - 50 Hz	Technical Manual 054369
15.0 EDT D-NET	Technical Manual 054600
17.0 EDE D-NET - 50 Hz	Technical Manual 054369
17.0 EDE D-NET - 60 Hz	Technical Manual 054369
21.0 EDE D-NET - 50 Hz	Technical Manual 053017
22.0 EDE D-NET	Technical Manual 054369
23.5 EDE D-NET - 50 Hz	Technical Manual 053017
25.5 EDE D-NET	Technical Manual 053017
26.0 EDE D-NET - 50 Hz	Technical Manual 053017
28.5 EDE D-NET	Technical Manual 053017
33.0 EDE D-NET	Technical Manual 053017
Gasoline Engines	
W 26G	Technical Manual 037425
W 26GX	Technical Manual 037425
Industrial Generators	
17.0 EDER - 50 Hz	Technical Manual 053017
20.0 EDER	Technical Manual 053017
21.0 EDER - 50 Hz	Technical Manual 053017
26.0 EDER	Technical Manual 053017
Low-CO EFI Gasoline Generators	
4.2 MCG low-CO - 50 Hz	Technical Manual 055743

4.2 SBCG low-CO - 50 Hz	Technical Manual 055051
5.0 MCG low-CO	Technical Manual 055743
5.0 SBCG low-CO	Technical Manual 055051
5.2 MCG low-CO - 50 Hz	Technical Manual 055743
5.4 SBCG low-CO - 50 Hz	Technical Manual 055051
6.4 SBEG low-CO - 50 Hz	Technical Manual 055050
6.5 MCG low-CO	Technical Manual 055743
6.5 SBCG low-CO	Technical Manual 055051
8.0 SBEG - 50 Hz low-CO	Technical Manual 055050
8.0 SBEG - 60 Hz low-CO	Technical Manual 055050
10.0 SBEG - 50 Hz low-CO	Technical Manual 055050
10.0 SBEG - 60 Hz low-CO	Technical Manual 055050
11.6 SBEG low-CO - 50 Hz	Technical Manual 055050
12.5 SBEG low-CO	Technical Manual 055050
14.0 SBEG low-CO	Technical Manual 055050
Universal Engines	
5411	Technical Manual 200151
5416	Technical Manual 200152
5421	Technical Manual 200151
5424	Technical Manual 200152
5432	Technical Manual 200153
5444	Technical Manual 200153
M2-12	Technical Manual 200155
M3-20	Technical Manual 200155
M3-20B	Technical Manual 200562
M4-30	Technical Manual 200155
M-12	Technical Manual 200155
M-15	Technical Manual 200151
M-18	Technical Manual 200155
M-20	Technical Manual 200152
M-25	Technical Manual 200151
M-25	Technical Manual 200155
M-25XP	Technical Manual 200155
M-25XPB	Technical Manual 200554
M-30	Technical Manual 200152
M-30	Technical Manual 200154
M-35	Technical Manual 200155
M-35B	Technical Manual 200554
M-40	Technical Manual 200154
M-40B	Technical Manual 200554
M-50	Technical Manual 200154
Westerbeke Engines	
04/01/0107	Technical Manual 020502
4-60	Technical and Parts Manual 016521
4-99	Technical Manual 020502
12B Two	Technical Manual 033403
12C Two	Technical Manual 055411
12D Two	Technical Manual 055411
20B Two	Technical Manual 037600
30B Three	Technical Manual 037600

30C Three	Technical Manual 037600
35B Three	Technical Manual 043444
35C Three	Technical Manual 045100
35D Three	Technical Manual 045100
35E Three	Technical Manual 045100
38B Four	Technical Manual 043440
42B Four	Technical Manual 043440
44A Four	Technical Manual 045100
44B Four	Technical Manual 045100
44C Four	Technical Manual 045100
55A Four	Technical Manual 43377
55B Four	Technical Manual 049970
55C Four	Technical Manual 049970
55D Four	Technical Manual 049970
63B Four	Technical Manual 032460
63C Four	Technical Manual 032460
65A Four	Technical Manual 053017
71B Four	Technical Manual 043317
71C Four	Technical Manual 043317
82B Four	Technical Manual 040485
90A Four	Technical Manual 043750
Century 80-N4	Technical Manual 047069
Century 110-T4	Technical Manual 047069
Century 120-N6	Technical Manual 047069
Century 170-T6	Technical Manual 047069
DS 5	Technical Manual 012310
DS 7	Technical Manual 012310
L-25	Technical and Parts Manual 019419
RD 60	Technical Manual 043444
RD 80	Technical Manual 043440
W 7	Technical Manual 012310
W 10 Two	Technical Manual 033403
W 13	Technical Manual 043444
W 13A	Technical Manual 043444
W 18	Technical Manual 043444
W 21	Technical Manual 043444
W 21A	Technical Manual 043444
W 27	Technical Manual 043440
W 27A	Technical Manual 043440
W 30	Technical Manual 011874
W 33	Technical Manual 043440
W 33A	Technical Manual 043440
W 40	Technical Manual 020502
W 46	Technical Manual 034907
W 50	Technical Manual 023156
W 52	Technical Manual 032460
W 58	Technical Manual 024331
W 60	Technical Manual 015204
W 70	Technical Manual 033355
W 100	Technical Manual 033355



Technical Library

<http://engine.od.ua>

