

-

Turbocharger


R4-3

OPERATING and MOUNTING INSTRUCTION for EXHAUST GAS TURBOCHARGER TYPE R4-3

Kompressorenbau Bannewitz GmbH
Windbergstraße 45
01728 Bannewitz
Federal Republic of Germany

Phone: +49 (351) 40 85 50
+49 (172) 35 16 045 (24 Hours Phone)
Fax: +49 (351) 40 85 840

Type plate

 Kompressorenbau Bannewitz GmbH	
Type/Works - No.	<input type="text"/>
Variants - No.	<input type="text"/>
max. Speed <input type="text"/> rpm	max. Temp <input type="text"/> °C
Weight <input type="text"/> kg	Year of Manuf. <input type="text"/>
Made in Germany	

The data given in the operating instructions apply only to the exhaust gas turbochargers of the works number mentioned above. This number is also given on the type plate affixed to the compressor housing of the exhaust gas turbocharger.

In case you have questions regarding the exhaust gas turbocharger, it is important to give the correct

- type
- variant number
- works number.

Only if these data are known the request can be handled properly and promptly.

Direct your requests to the following addresses:

Kompressorenbau Bannewitz GmbH
Windbergstr. 45
01728 Bannewitz
Federal Republic of Germany

Fax: +49 (351) 40 85 840
Phone: +49 (351) 40 85 50
+49 (172) 35 16 045 (24 Hours Phone)

Table of Contents

Chapter	Title	Page
1	SAFETY.....	5
1.1	Built-in safety systems.....	5
1.2	Safety measures (to be taken by operator)	5
2	GENERAL INFORMATION ABOUT DANGERS.....	6
2.1	Danger zone.....	6
2.2	Operators and maintenance personnel.....	6
2.3	Use of spare parts and wearing parts	7
3	DESIGN AND SPECIFICATIONS.....	8
3.1	Brief description	8
3.2	Operating data	9
3.3	Pipe connections.....	10
3.4	Test connections	11
3.5	Dimensions of important subassemblies	12
4	INSTRUCTIONS FOR MOUNTING TURBOCHARGER.....	13
4.1	General requirements.....	13
4.2	Console for the TC	13
4.3	Gas and air pipings	13
4.4	Loads of housings of the exhaust gas turbocharger	14
4.5	Vibrations.....	14
5	OPERATION.....	15
5.1	Preparation for operation	15
5.1.1	Lubricating oil supply	15
5.1.2	Cooling water	15
5.2	Engine operation	16
5.3	Putting out of operation.....	16
5.4	Failures.....	17
6	MAINTENANCE.....	18
6.1	General.....	18
6.2	Maintenance work	18
6.3	Cleaning.....	19
6.4	Maintenance schedule	20
6.5	Troubleshooting table	21

Chapter	Title	Page
7	DISASSEMBLY AND ASSEMBLY	22
7.1	Introduction	22
7.2	Checking the components	22
7.3	Test results	24
7.4	Clearance sheet	26
7.5	Process of maintenance	27
7.5.1	Compressor washing	27
7.5.2	Turbine washing	28
7.5.3	Stoppage the exhaust gas turbocharger	29
7.5.4	Bearing check	30
7.5.5	Disassembly of the complete turbocharger	31
7.5.6	Assembly of the complete turbocharger	32
7.5.7	Assembly and disassembly of silencer or air-intake housing	33
7.5.8	Cleaning the silencer	34
7.5.9	Assembly and disassembly of the compressor housing	35
7.5.10	Assembly and disassembly of the bearing housing with rotor	36
7.5.11	Disassembly of rotor complete	37
7.5.12	Installation of rotor complete	39
7.5.13	Disassembly turbine outlet housing	42
8	SPARE PARTS AND TOOLS	43
8.1	General	43
8.2	Spare parts	44
8.2.1	Bearings	44
8.2.2	Gaskets	45
8.2.3	Locking elements	46
8.3	Tools	47
9	SECTIONAL DRAWING	48
10	LIST OF COMPONENTS	49